


Service Manual

Cassette Deck

RS-B78R

 (Silver Face)
 (Black Face)

 dbx/Dolby B-C NR, Auto-Reverse
 Cassette Deck

 This is the Service Manual
 for the following areas.

D ...For all European
 areas except United
 Kingdom.

B ...For United Kingdom.

N ...For Asia, Latin
 America, Middle
 East and Africa
 areas.

A ...For Australia.

RS-8R MECHANISM SERIES

Specifications

Track system: 4-track 2-channel stereo recording
and playback

Tape speed: 4.8cm/s

Wow and flutter: 0.045% (WRMS), $\pm 0.14\%$ (DIN)

Frequency
response: Metal tape; 20~20,000Hz
30~19,000Hz (DIN)
40~18,000Hz $\pm 3\text{dB}$
CrO₂ tape; 20~19,000Hz
30~18,000Hz (DIN)
40~17,000Hz $\pm 3\text{dB}$
Normal tape; 20~18,000Hz
30~17,000Hz (DIN)
40~16,000Hz $\pm 3\text{dB}$

Dynamic range: 110dB (at 1kHz) with dbx in

Max. input level
improvement: 10dB or more improved with dbx in
(at 1kHz)

Signal-to-noise
ratio: dbx in; 92dB (A weighted)
Dolby C NR in; 75dB (CCIR)
Dolby B NR in; 68dB (CCIR)
NR out; 58dB (A weighted)
(Signal level = max. input level CrO₂
type tape)

Fast forward and
rewind time: Approx. 90 seconds with C-60
cassette tape

Inputs: MIC; sensitivity 0.25mV, applicable
microphone impedance
400 Ω ~10k Ω
LINE; sensitivity 60mV, input
impedance 47k Ω or more

Outputs: LINE; output level 700mV, output
impedance 800 Ω or less
HEADPHONES; output level 125mV
(at 8 Ω) applicable headphone
impedance 8 Ω ~600 Ω

Bias frequency: 80kHz

Heads: 1-AX (AMORPHOUS) head for
rec/playback
2-double-gap ferrite head for erasure

Motor: 3-motor system
One for capstan drive (Electrical
governor motor)
One for reeltable drive (DC motor)
One for mechanism drive (DC motor)

Technics


 Matsushita Electric Trading Co., Ltd.
 P.O. Box 288, Central Osaka Japan

Service Manual

**dbx/Dolby B-C NR, Auto-Reverse
Cassette Deck**

**Cassette Deck
RS-B78R
(Silver Face)
(Black Face)**

DOLBY B-C NR



This is the Service Manual
for the following areas.

D ...For all European
areas except United
Kingdom.

B ...For United Kingdom.

N ...For Asia, Latin
America, Middle
East and Africa
areas.

A ...For Australia.

RS-8R MECHANISM SERIES

Specifications

Track system: 4-track 2-channel stereo recording
and playback

Tape speed: 4.8cm/s

Wow and flutter: 0.045% (WRMS), $\pm 0.14\%$ (DIN)

Frequency response: Metal tape; 20~20,000Hz
30~19,000Hz (DIN)
40~18,000Hz ± 3 dB
CrO₂ tape; 20~19,000Hz
30~18,000Hz (DIN)
40~17,000Hz ± 3 dB
Normal tape; 20~18,000Hz
30~17,000Hz (DIN)
40~16,000Hz ± 3 dB

Dynamic range: 110dB (at 1kHz) with dbx in

Max. input level improvement: 10dB or more improved with dbx in
(at 1kHz)

Signal-to-noise ratio: dbx in; 92dB (A weighted)
Dolby C NR in; 75dB (CCIR)
Dolby B NR in; 68dB (CCIR)
NR out; 58dB (A weighted)
(Signal level = max. input level CrO₂
type tape)

Fast forward and
rewind time: Approx. 90 seconds with C-60
cassette tape

Inputs: MIC; sensitivity 0.25mV, applicable
microphone impedance
400 Ω ~10k Ω
LINE; sensitivity 60mV, input
impedance 47k Ω or more

Outputs: LINE; output level 700mV, output
impedance 800 Ω or less
HEADPHONES; output level 125mV
(at 8 Ω) applicable headphone
impedance 8 Ω ~600 Ω

Bias frequency: 80kHz

Heads: 1-AX (AMORPHOUS) head for
rec/playback
2-double-gap ferrite head for erasure

Motor: 3-motor system
One for capstan drive (Electrical
governor motor)
One for reeltable drive (DC motor)
One for mechanism drive (DC motor)

Technics

Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan

Power

requirements: AC; 110/125/220/240V, 50-60Hz

□...Pre-set power voltage 220V

□N□A...Pre-set power voltage 240V

Power

consumption: 25W

Dimensions: 43cm(W)×9.8cm(H)×27.3cm(D)

Weight: 5.3kg

Design and specifications are subject to change without notice.


*The term dbx is a registered trademark of dbx Inc.


** 'Dolby' and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

CONTENTS

ITEM	PAGE	ITEM	PAGE
• Location of Controls and Components	2	• Schematic Diagram (for Main/FL meter Section)	24
• Operating Instruction	3	• Schematic Diagram (for Mechanism/ Mechanism Control Section)	28
• Disassembly Instructions	4	• Electrical Parts List	30
• Precautions in Disassembly and Reassembly	6	• Circuit Boards and Wiring Connection Diagram	33
• Precautions for Parts Replacement	6	• Mechanical Parts Location (included Parts List)	36
• Replacing Rotary Head Assembly	7	• Cabinet Parts Location (included Cabinet, Accessories and Packing Parts List)	37
• Measurement and Adjustment Methods	7		
• Microcomputer Terminal Function and Waveform ...	14		
• Block Diagram	21		

LOCATION OF CONTROLS AND COMPONENTS





OPERATING INSTRUCTION

About direct music select function

After searching for the beginning of your desired programs, the unit will begin playback automatically.

1. Select the playback side

Each time the Direct Music Select Button is pressed, the unit will switch between forward and reverse playback. (The Forward or Reverse Indicator will light in the respective modes).

2. Select the programs

Press the Set Buttons of the programs you wish to hear (the buttons pressed will light).

- Programs are always counted from the beginning of the tape, first program, second program... etc.
- If the first program is set, the tape will automatically rewind to the beginning and enter the stop mode.
- If a button is pressed by mistake, pressing it once more will release it (its light goes out).

To listen to the 5th, 9th, and 2nd programs from the tape's beginning:

Press Set Button 5, 9, and 2 in that order.

To listen to set programs repeatedly:

If the D.M.S. Repeat Button is pressed, the set programs will be played back repeatedly (the D.M.S. Repeat Indicator will light, indicating that the D.M.S. repeat function is operating).

3. Begin playback

When the Play Button is pressed, the set programs will begin playback. (Programs not set will be skipped over automatically by the fast forward and rewind functions).

To cancel direct music select:

Press the Stop Button.

To cancel D.M.S. repeat:

Press the D.M.S. Repeat Button once again (the D.M.S. Repeat Indicator goes out).

Notes:

- During D.M.S. repeat playback, the unit will playback repeatedly a maximum of 16 times unless the Stop Button is pressed earlier.
- Playback in the direct music select mode is in the order in which the Set Buttons are pressed.
- Use the cassette tape's index card to note the names and order of programs recorded; this makes use of the Set Buttons more convenient.
- This may not operate correctly with the following kinds of tape: programs with passages of extremely low volume level, music tapes with non-recorded passages, recordings with sections of fade-in or fade-out recording.
- Unrecorded blanks of about 4 seconds in length between the program must be created in order for the music selector function to work properly.
The function may not work if the blanks are too short.
The function may not work properly with prerecorded music tapes which have passages where the sound level is particularly low or which have passage of unrecorded sound.
- In cases such as classic music, when a low level of sound continues in the program.
- Do not use pause between music pieces during D.M.S. operation. (This may cause erroneous operation for counting of the number of music pieces.)
- On a music tape to be played back with direct music select, there has to be an unrecorded space of at least four seconds between the end of the last tune on the tape and the beginning of the leader tape; if there is not, an operational error may occur.
- Additional settings of song numbers not yet used can be made while D.M.S. playback is in progress.
However, numbers of songs already played-back by D.M.S. should not be re-entered during D.M.S. playback because the next D.M.S. song number will be cancelled each time the select key of a previously played song is pressed.
- Do not cancel D.M.S. playback during about the first 8 seconds of a song to prevent an erroneous operation when D.M.S. playback is used again.
- Check the total number of songs on a cassette before entering song numbers for D.M.S. playback.
If a non-existent song number is entered (for example, song 6 for a cassette side having only 5 songs), the D.M.S. function may not operate properly.
If this occurs, press the stop Button.

DISASSEMBLY INSTRUCTIONS




Fig. 1




Fig. 2






Fig. 3

(H) How to remove flat cable



Open the lid of connector in the direction of the arrow as shown left-hand, and extract the flat cable to disconnect.

(R) How to remove nylon rivet



To remove a heat sink from the back chassis, first press nylon rivet-A from the inside in the direction indicated by the arrow as shown above, and extract the rivet to the outside. Next remove nylon rivet-B from the outside. Consequently, the heat sink can be removed from the back chassis.




Fig. 4




Fig. 5




Fig. 6




Fig. 7




Fig. 8




Fig. 9

Ref. No.	Procedure	To remove —.	Remove —.	Shown in fig. —.
1	1	Case cover	• 2 ornament screws(A) • 3 screws(B) • As shown in fig. 1, pull case cover in the direction of arrow ①.	1 2 1
2	1 → 2	Front panel assembly and mechanism unit	• 3 screws(C) • 2 screws(D) • 2 screws(E) • 2 screws(F) • Pull out the connectors A B F G H N O P Q R W 1(G) • How to remove flat cable(H)	3, 4, 5 6 6 6 3 3
3	1 → 3	Mechanism unit	• Push the eject button(I) • Cassette lid(J) • 2 screws(E) • 2 screws(F) • 2 screws(K)	1 1 6 6 7
4	1 → 4	Slide volume assembly	• 2 screws(L)	7
5	1 → 4 → 5	FL meter circuit	• 1 screw(M) • 4 screws(N) • As shown in fig. 7, raise the clumper in the direction of arrow ② and remove the FL meter circuit in the direction of arrow ③.	7 7 7
6	6	Bottom cover	• 2 screws(D) • 2 screws(F) • 7 screws(O) • Slide the bottom cover in the direction arrow ④ and remove it.	6 6 6 6
7	1 → 6 → 7	Mechanism control circuit board	• 1 screw(C) • 1 screw(P) • How to remove flat cable(H) • Remove the locking support from the board while pushing its tip in the direction of arrow.(Q)	4 3 3 3
8	1 → 6 → 7 → 8	Main circuit board	• How to remove nylon ribet(R)	3
9	1 → 3 → 9	FF/REW motor and driver motor	• Remove the reel table(S) • 4 screws(T) • Un solder the soldered portion of the FF/REW motor terminal and driver motor terminal(U)	8 8 9
10	1 → 3 → 10	Capstan motor	• 5 screws(V)	9

PRECAUTIONS IN DISASSEMBLY AND REASSEMBLY

Removing the Mode Select Button

The Mode Select Buttons are press-fit with the Button Bushings, as shown in Fig. 10, with the Front Panel Assembly and Button Springs between them. Remove the Button Bushings using pliers to disassemble these parts. Be careful not to lose the Button Springs as they will pop out.

Reassembling the Mechanism Unit

1. For repair, measurement or adjustment with the mechanism removed from the unit be sure to ground the lower base plate of the mechanism.

For grounding, connect an extension cord to the mechanism's lower base plate and the lug terminal from amplifier printed circuit board.

Without grounding, the mechanism does not operate properly. (Refer to Fig. 11).




Fig. 10




Fig. 11

PRECAUTIONS FOR PARTS REPLACEMENT

Replacement of the Blank Skip/Time/Tape, Counter Reset and DMS (1 — 12) Buttons.

The Blank Skip, Time Count and Tape Count Buttons are a one-piece resin molded part (It is supplied as a single part.).

As shown in Fig. 1, this buttons are fixed in such a manner that the Front Panel Assembly is sandwiched between the Ornament Plate (G5-1) and the buttons and five pins (A) are melted by heat. (Five pins (B) are used to fix the Ornament Plate. Refer to Fig. 2.)

To remove this part, first, remove the two lugs on the Ornament Plate from the Front Panel. Then, while pulling part (C) of the Ornament Plate toward the front, heat the ten pins (A) and (B) with a soldering iron. (Refer to the Fig. 2.) When the button retainer plate is removed at this time, buttons DMS 1 to 12 can be replaced.

As mentioned above, this part is fixed by melting the pins by heat, both the Ornament Plate and button must be replaced when replacement is required.





Fig. 1



Button Retainer Plate Fig. 2

Replacement of Parts on the Keyboard Circuit

To replace the parts on the keyboard circuit, first, remove the eight screws (F), and then desolder two terminals (G) of LED's (D519). The Operation Chassis can then be removed from the Base Plate and the parts be replaced. (Refer to Fig. 3).




Fig. 3

REPLACING ROTARY HEAD ASSEMBLY

Considerations in mounting the rotary head assembly

1. This recorder requires a record/playback head of extremely precise head height. In replacing the rotary head, install a factory-adjusted full rotary head assembly.
[Never attempt to disassemble the rotary head assembly by removing screws (A).]
2. In installing the replacement rotary head assembly, make certain that the change gear is placed at location (B) on the change rod. (See Fig. 1.)
3. Trace the record/playback head lead-wire as follows (Refer to Fig. 2):
 - Set the record/playback head in its forward stop direction.
 - At this time, hook the head wire to the clamber of the pinch roller R, and press the head wire in the direction of the arrow as shown in Fig. 2 so that it is bent approximately 90 degrees. Then secure the wire on the mechanism unit using a cord clamber.




Fig. 1




Fig. 2

MEASUREMENT AND ADJUSTMENT METHODS




Fig. 1

NOTES: Set switches and controls in the following positions, unless otherwise specified.

- Make sure heads are clean
- Make sure capstan and pressure roller are clean
- Judgeable room temperature $20 \pm 5^\circ\text{C}$ ($68 \pm 9^\circ\text{F}$)
- NR switch: OUT
- Timer start switch: OFF
- Balance control: Center
- Input level control: Maximum
- Output level control: Maximum
- Mode switch:  mode
- Blank skip switch: OFF
- Music select switch: OFF
- Music repeat switch: OFF

A Head adjustment

Condition:
 • Playback mode
 (Forward • Reverse)
 • Normal tape mode

Equipment:
 • VTVM
 • Oscilloscope
 • Test tape (azimuth)...QZZCFM
 • Test tape QZZCRD

HEAD HEIGHT ADJUSTMENT

- Turn the erase head height adjustment screws on the rotary head assembly counterclockwise until the upper end face of the erase heads is aligned on the same plane as the top face of their respective guide pins. (Refer to figs. 2 and 3.)
- Put a point ink-mark on the head of each adjustment screw. 
- With the marks as guides, turn the erase head height adjustment screw 3.2 turns clockwise. 
- Install a test tape (tape with mirror: QZZCRD) on the recorder; place the recorder in the FORWARD PLAY mode. Make fine adjustments of the erase head height as necessary, to attain on the record/playback head face the tape position shown in fig. 4.
- Run the tape in the forward play mode and check it for zigzag running. (Shown in fig. 4)
If zigzag tape running occurs, repeat step 4.
- Place the recorder in the reverse play mode and perform the above steps 4 and 5.
- Repeat steps 5 and 6 two or three times and verify that the tape position shown in fig. 4 is ensured.




Fig. 2




Fig. 3




Fig. 4

L-CH/R-CH output balance adjustment

- Make connections as shown in fig. 5.
- In the forward playback mode, playback the 8kHz signal from the test tape (QZZCFM). Adjust the azimuth screw (Forward) shown in fig. 6 for maximum output L-CH and R-CH levels. When the output levels of L-CH and R-CH are not at maximum at the same point adjust as follows.
- Turn the azimuth screw (Forward) shown in fig. 6 to find angles A and C (points where peak output levels for left and right channels are obtained). Then, locate angle B between angles A and C, i.e., point where L-CH and R-CH outputs are balanced. (Refer to figs. 6 and 7.)
- In the reverse playback mode, adjust the azimuth screw (reverse) in the same way described above.




Fig. 5




Fig. 6




Fig. 7

L-CH/R-CH phase adjustment

- Make connections as shown in fig. 8.
- In the forward playback mode, playback the 8kHz signal from the test tape (QZZCFM). Adjust the azimuth screw (Forward) shown in fig. 6 so that pointers of the two VTVMs swing to maximum and a lissajous waveform as illustrated in fig. 9 is obtained on the oscilloscope.
- In the reverse playback mode, adjust the azimuth screw (reverse) in the same way described above.




Fig. 8




Fig. 9


Checking the difference in level between forward and reverse running

15. Reproduce the playback level adjustment signal (315 Hz at 0 dB) on the standard playback adjustment tape; and check that the difference between the level in forward running and that in reverse running is within 1.0 dB.
16. After adjustment, lock the erase head height and angle adjustment screws.

Head Height Adjustment using the Head Adjustment Jig (QZZ0207)

The head adjustment jig (QZZ0207) enables accurate, speedy head height adjustment in the following manner.

- a. Place the plate onto the mechanism.
- b. Set the mechanism to the PLAY mode.
- c. Place the check bar onto the plate.
- d. Pass the check bar through each erase head.
- e. Adjust the height screw so that the check bar does not touch any of the erase heads.
- f. Run a mirror tape (QZZCRD) and check to see that the tape does not touch (twist around, etc.) the erase heads.
- g. After that, adjust items 4 thru 13 in the adjustment procedure.

**㊦ Takeup torque**

Condition:
• Playback mode

Equipment:
• DC voltmeter
• Test tape...QZZSRKCT

1. Set the test tape (or RT-60) into the cassette holder.
2. Adjust the takeup torque adjusting potentiometer VR601 in the forward playback mode for 3.5 volts between the FF/REW motor terminals.
3. Run the QZZSRKCT takeup torque measurement tape in the forward playback mode and check that the torque is within quoted tolerance.

Standard value: 50 ± 10 gr-cm

㊦ Tape speed

Condition:
• Playback mode

Equipment:
• Digital frequency counter
• Test tape...QZZCWAT

Tape speed accuracy

1. Test equipment connection is shown in fig. 10.
2. Playback test tape (QZZCWAT 3,000 Hz), and supply playback signal to the digital frequency counter.
3. Measure this frequency.
4. On the basis of 3,000 Hz, determine value by following formula:

$$\text{Tape speed accuracy} = \frac{f - 3,000}{3,000} \times 100(\%) \quad \text{where, } f = \text{measured value}$$

5. Take measurement at middle section of tape.

Standard value: ± 1.5%

6. If measured value is not within the standard value, adjust it by using the tape speed adjustment VR shown in Fig. 1.




Fig. 10

Tape speed fluctuation

Make measurements in same manner as above (beginning, middle and end of tape), and determine the difference between maximum and minimum values and calculate as follows:

$$\text{Tape speed fluctuation} = \frac{f_1 - f_2}{3,000} \times 100(\%) \quad f_1 = \text{maximum value, } f_2 = \text{minimum value}$$

Standard value: Less than 1%

NOTE:

Please use non metal type screwdriver when you adjust tape speed on this unit.

D Playback frequency response

Condition:

- Playback mode (Forward • Reverse)
- Normal tape mode

Equipment:

- VTVM
- Oscilloscope
- Test tape...QZZCFM

1. Test equipment connection is shown in fig. 5.
2. Playback the frequency response portion of test tape (QZZCFM).
3. Measure output level at 315Hz, 12.5kHz, 8kHz, 4kHz, 1kHz, 250Hz, 125Hz and 63Hz, and compare each output level with the standard frequency 315Hz, at LINE OUT.
4. Make measurements for both channels.
5. Make sure that the measured values are within the range specified in the frequency response chart. (Shown in fig. 11).

Playback frequency response (Forward • Reverse)




Fig. 11

E Playback gain

Condition:

- Playback mode
- Normal tape mode
- Output level control...MAX.
- Balance control...Center

Equipment:

- VTVM
- Oscilloscope
- Test tape...QZZCFM

1. Test equipment connection is shown in fig. 5.
2. Playback standard recording level portion on test tape (QZZCFM 315Hz) and, using VTVM, measure the output level at test points [TP7 (L-CH), TP8 (R-CH)].
3. Make measurements for both channels.

Standard value: $0.42 \pm 0.05V$ [around 0.28V: at test points TP7 (L-CH) and TP8 (R-CH)]

Adjustment

1. If the measured value is not within standard the adjust VR1 (L-CH) or VR2 (R-CH) (See fig. 1).
2. After adjustment, check "Playback frequency response" again.

F Erase current

Condition:

- Record mode (Forward • Reverse)
- Metal tape mode

Equipment:

- VTVM
- Oscilloscope

1. Test equipment connection is shown in fig. 12.
2. Place UNIT into metal tape mode.
3. Press the record and pause buttons.
4. Read voltage on VTVM and calculate erase current by following formula:

$$\text{Erase current (A)} = \frac{\text{Voltage across resistor R201}}{1 (\Omega)}$$

Standard value: $155 \pm 15mA$ (Metal)




Fig. 12

Adjustment

- If the measured value is not within standard value, adjust VR305 (Forward) or VR306 (Reverse) (See fig. 1).

G Overall frequency response

Condition:

- Record/playback mode (Forward • Reverse)
- Normal tape mode
- CrO₂ tape mode
- Metal tape mode
- Input level control...MAX
- Output level control...MAX
- Balance control...Center

Equipment:

- VTVM
- ATT
- AF oscillator
- Oscilloscope
- Resistor (600Ω)
- Test tape (reference blank tape)
 - ...QZZCRA for Normal
 - ...QZZCRX for CrO₂
 - ...QZZCRZ for Metal

Note:

Before measuring and adjusting, the overall frequency response make sure of the playback frequency response (For the method of measurement, please refer to the playback frequency response).

(Recording equalizer is fixed)

1. Make connections as shown in fig. 13.
2. Place UNIT into normal tape mode and insert the normal reference blank test tape (QZZCRA).
3. Supply a 1kHz signal from the AF oscillator through ATT to LINE IN.
4. Adjust ATT so that input level is -20dB below standard recording level (standard recording level = 0 VU).
5. Adjust the AF oscillator frequency to 1kHz, 50Hz, 100Hz, 200Hz, 500Hz, 4kHz, 8kHz, 10kHz and 12.5kHz signals, and record these signals on the test tape.
6. Playback the signals recorded in step 5, and check if the frequency response curve is within the limits shown in the overall frequency response chart for normal tapes (fig. 14). (If the curve is within the charted specifications, proceed to steps 7, 8 and 9.)
If the curve is not within the charted specifications, adjust as follows;




Fig. 13


Overall frequency response chart (Normal)

Fig. 14

Adjustment (A):

When the curve exceeds the overall specified frequency response chart (fig. 14) as shown in fig. 15.

- 1) Increase bias current by turning VR301 (L-CH) and VR302 (R-CH). (See fig. 1 on page 7.)
- 2) Repeat steps 5 and 6 for confirmation (Proceed to steps 7, 8 and 9 if the curve is now within the charted specifications as shown fig. 14.)
- 3) If the curve still exceeds the specifications (fig. 14), increase bias current further and repeat steps 5 and 6.




Fig. 15

Adjustment (B):

When the curve falls below the overall specified frequency response chart (fig. 14) as shown in fig. 16.

- 1) Reduce bias current by turning VR301 (L-CH) and VR302 (R-CH).
- 2) Repeat steps 5 and 6 for confirmation (Proceed to steps 7, 8 and 9 if the curve is now within the charted specification as shown fig. 14.)
- 3) If the curve still falls below the charted specifications (fig. 14), reduce bias current further and repeat steps 5 and 6.




Fig. 16

7. Place UNIT into CrO₂ tape mode.
8. Change test tape to CrO₂ reference blank test tape (QZZCRX), and record 1kHz, 50Hz, 100Hz, 200Hz, 500Hz, 4kHz, 8kHz, 10kHz and 15kHz signals. Then, playback the signals and check if the curve is within the limits shown in the overall frequency response chart for CrO₂ tapes (fig. 17).
9. Place UNIT into metal tape mode and change test tape to metal reference blank test tape (QZZCRZ), and record 1kHz, 50Hz, 100Hz, 200Hz, 500Hz, 4kHz, 8kHz, 10kHz, 12.5kHz and 15kHz signals. Then, playback the signals and check if the curve is within the limits shown in the overall frequency response chart for metal tapes (fig. 17).
10. Confirm that bias currents are approximately as follows when the UNIT is set at different tape mode.
 - Read voltage on VTVM between ground and test point (TP3 for L-CH, TP4 for R-CH) and calculate bias current by following formula:

$$\text{Bias current (A)} = \frac{\text{Value read on VTVM (V)}}{10 (\Omega)}$$

around 200μA (Normal position)
Standard value: around 250μA (CrO₂ position)
around 430μA (Metal position)


Overall frequency response chart (CrO₂, Metal)

Fig. 17

Ⓐ Overall gain

Condition:

- Record/playback mode (Forward • Reverse)
- Normal tape mode
- Input level control...MAX
- Output level control...MAX
- Balance control...Center
- Standard input level;

MIC $-72 \pm \frac{4}{2}$ dB

LINE IN $-24 \pm \frac{4}{2}$ dB

Equipment:

- VTVM
- ATT
- Resistor (600Ω)
- Test tape (reference blank tape) ...QZZCRA for Normal
- AF oscillator
- Oscilloscope

1. Test equipment connection is shown in fig. 18.
2. Insert the normal reference blank tape (QZZCRA).
3. Place UNIT into record mode.
4. Supply a 1kHz signal through ATT (-24dB) from AF oscillator, to LINE IN.
5. Adjust ATT until monitor level at LINE OUT becomes 0.42V.
6. Playback recorded tape, and make sure that the output level at LINE OUT becomes 0.42V.
7. If measured value is not $0.42V \pm 2dB$, adjust it by using VR3 (L-CH) or VR4 (R-CH).
8. Repeat from step (2).

Standard value: $0.42V \pm 2dB$

[around 0.28V: at test points TP7 (L-CH) and TP8 (R-CH)]




Fig. 18

Ⓑ Dolby NR circuit

Condition:

- Record mode
- Dolby NR switch...IN/OUT
- Dolby NR select switch...B/C
- Input level control...MAX
- Output level control...MAX
- Balance control...Center

Equipment:

- VTVM
- ATT
- Resistor (600Ω)
- AF oscillator
- Oscilloscope

Record side

• Check of the Dolby-B type encoder characteristics

1. Make connections as shown in fig. 19.
2. Set the unit to the record mode. (NR select switch is OUT.)
3. Apply a 1kHz signal to LINE IN.
4. Adjust the ATT so that the output level at TP7 (L-CH) and TP8 (R-CH) is 12.3mV.
5. The output level at pin 14 should also be 12.3mV. (Let 12.3mV = 0dB for this adjustment.)
6. Set the NR select switch to B, and make sure that the output signal level at pin 14 of IC3 (L-CH) and IC4 (R-CH) is $+6dB \pm 2.5dB$.
7. Set the NR select switch to OUT, and adjust the frequency to 5kHz. The output signal level at pin 14 should be 0dB.
8. Set the NR select switch to B and make sure that the output signal level at pin 14 of IC3 (L-CH) and IC4 (R-CH) is $+8dB \pm 2.5dB$.

• Check to Dolby-C type encoder characteristics

9. Repeat steps 1-5 above.
10. Set the NR select switch to C and make sure that the output signal level at pin 14 of IC3 (L-CH) and IC4 (R-CH) is $+11.5dB \pm 2.5dB$.
11. Set the NR select switch to OUT and adjust the frequency to 5kHz. The output signal at pin 14 should be 0dB.
12. Set the NR select switch to C and make sure that the output signal level at pin 14 of IC3 (L-CH) and IC4 (R-CH) is $+8.5dB \pm 2.5dB$.




Fig. 19

⑨ Attack recovery time adjustment (dbx circuit)

Condition:
 • Record mode
 • Input level control...MAX
 • Noise reduction selector
 ...dbx tape

Equipment:
 • VTVM
 • ATT
 • AF oscillator
 • DC voltage

1. Make the connections as shown in fig. 20 and apply 1kHz -27dB signal from LINE IN, and set the noise reduction selector to dbx tape position.
2. Set the unit to record mode, adjust ATT so that the signal level at C107 (L-CH) and C108 (R-CH) is 300mV.
3. Read voltage on DC volt meter.

Reference value: $15 \pm 0.5\text{mV}$

4. If measured value is not within reference, adjust VR11 (shown in fig. 1).




Fig. 20

⑩ Input scanning time adjustment

Condition:
 • Stop mode

Equipment:
 • Oscilloscope

1. Place the recorder in the stop mode.
2. Connect an oscilloscope to pin 2 of IC401, as shown in fig. 21.
3. Make sure that the measured values are within the reference value.

Reference value: Approx. 4.6msec.




Fig. 21

⑪ Fluorescent meter

Condition:
 • Record mode
 • Input level controls...MAX

Equipment:
 • VTVM
 • ATT
 • AF oscillator

• Check for FL meter

To check the accuracy of the FL meter, measure the output level at test point [TP7 (L-CH), TP8 (R-CH)].

1. Make connections as shown (See fig. 22).
2. Connect a wire between TP501 and TP502 terminal (See fig. 23).
3. In the recording pause mode, apply 1kHz (-24dB) to LINE IN.
4. Adjust ATT so that output level at test point [TP7 (L-CH), TP8 (R-CH)] is 0.28V.

Checking FL meter 0dB segment display ON/OFF

Change the output level at test point [TP7 (L-CH), TP8 (R-CH)] from 0.28V -1dB ($\approx 250\text{mV}$) to 0.28V +1dB ($\approx 310\text{mV}$) by adjusting the attenuator, and check that the FL meter 0dB segment display OFF state changes to the ON state.

Checking FL meter -40dB segment display ON/OFF

Lower the signal level 28dB below the standard input level (-24dB-28dB=-52dB $\approx 2.5\text{mV}$) and then further lower the level 12dB (-52dB-12dB=-64dB $\approx 0.63\text{mV}$) by adjusting the attenuator. While lowering the level as described above, make sure that only the -40dB display remains lit the dims or goes off at the lowest level.

• Adjustment for FL meter

1. Make connections as shown (See fig. 22).
2. Connect a wire between TP501 and TP502 terminal (See fig. 23).
3. In the recording pause mode, apply 1kHz (-24dB) to LINE IN.
4. Adjust ATT so that output level at test point [TP7 (L-CH), TP8 (R-CH)] is 0.28V.

-40dB adjustment

5. Adjust ATT so that the level adjusted at step 4 is reduced by 40dB.
6. At this time, check that -40dB indicator is dimmed (intermediate brightness between full brightness and light-out: See fig. 24).
7. If the indicator is not lighted halfway as described in step 6, adjust VR8.




Fig. 22




Fig. 23




Fig. 24

0dB adjustment

8. Restore the condition of step 4 (set output level to 0.28V at test point [TP7 (L-CH), TP8 (R-CH)]).
9. At this time, check that 0dB indicator is dimmed (intermediate brightness between full brightness and light-out (See fig. 25).
10. If improper, adjust VR501.
11. Repeat adjustments at steps 4, 5, 6, 7, 8, 9 and 10 two or three times.
12. Disconnect the wire between TP501 and TP502 terminal, which had been connected at step 2.



Fig. 25

Photo sensor circuit

Condition:
• Playback mode

NOTE:

When adjusting the photo sensor circuit, leave the front panel, cassette lid and indication plate in place. (External light can cause the photo sensor in the cassette holder to malfunction and makes accurate adjustment impossible.)

Sensitivity adjustment

Some malfunctions, such as tape reverse or auto stop, may sometimes occur during tape travel according to type and make of tape. If the trouble is caused only by tape wrinkles, perform the following adjustments.




1. While playing the section causing malfunction, adjust VR303 so that normal operation is obtained. (Shown in fig. 1).
2. Then play the leader tape section and check for normal operation (that tape reverse and auto stop are eliminated).








MICROCOMPUTER TERMINAL FUNCTION AND WAVEFORM (IC401: MN1564RME)





Terminal No.	Symbol	Name	Function/operation
1.	VSS	GND	
2.	$P\phi\phi$	FL grid & input switch scanning	Pulse width: T_a = Approx. 1.0msec, T_b = Approx. 80μsec.
3.	$P\phi 1$		
4.	$P\phi 2$		
5.	$P\phi 3$		
6.	ST0	_____	• Non connection.
7.	$P1\phi$	Reading of input switch state REW • STOP • TIME	• Reads switch inputs corresponding to scanning of $P\phi\phi$ to $P\phi 3$. As each switch is pressed, the corresponding shaded section goes low.




Terminal No.	Symbol	Name	Function/operation
8.	P11	Reading of input switch state FF • PAUSE • TAPE	• Reads switch inputs corresponding to scanning of Pφφ to Pφ3. As each switch is pressed, the corresponding shaded section goes low. TAPE PAUSE FF
9.	P12	Reading of input switch state REC • PLAY • TIMER • PLAY • COUNTER RESET	• Reads switch inputs corresponding to scanning of Pφφ to Pφ3. As each switch is pressed, the corresponding shaded section goes low. COUNTER TIMER PLAY REC RESET PLAY
10.	P13	Reading of input switch state DIR • TIMER REC	As each switch is pressed, the corresponding shaded section goes low. TIMER REC DIR
11.	ST1		Non connection. SYNC: Output waveforms during operation. Approx. 0.5μsec. Approx. 1.5μsec.
12.	SYNC		
13.	SIRQ		
14.	IRQ		
15.	SBT		
16.	SBD		
17.	RST	Reset terminal	• Terminal for reset signal to computer. • Automatically reset at not more than 3.5 to 4.0V. 5.4V 4.0V L Power ON 0.6sec.
18.	P2φ	Reading of input switch state AUTO REC MUTE • 1 • 5 • 9	• Reads switch inputs corresponding to scanning of Pφφ to Pφ3. As each switch is pressed, the corresponding shaded section goes low. 1 5 9 AUTO REC MUTE

Terminal No.	Symbol	Name	Function/operation
19.	P21	Reading of input switch state DMS • 2 • 6 • 10	• Reads switch inputs corresponding to scanning of Pφφ to Pφ3. As each switch is pressed, the corresponding shaded section goes low. 2 6 10 D.M.S
20.	P22	Reading of input switch state REPEAT • 3 • 7 • 11	• Reads switch inputs corresponding to scanning of Pφφ to Pφ3. As each switch is pressed, the corresponding shaded section goes low. 3 7 11 REPEAT
21.	P23	Reading of input switch state B.S • 4 • 8 • 12	• Reads switch inputs corresponding to scanning of Pφφ to Pφ3. As each switch is pressed, the corresponding shaded section goes low. 4 8 12 B.S
22.	P3φ	Dynamic lighting indication FWD • 1 • 5 • 9 LED	• Four corresponding LEDs light one at a time in accordance with the scanning of Pφφ to Pφ3. As each switch is pressed, the corresponding shaded section goes low. 1 5 9 FWD
23.	P31	Dynamic lighting indication REV • 2 • 6 • 10 • LED	• Four corresponding LEDs light one at a time in accordance with the scanning of Pφφ to Pφ3. As each switch is pressed, the corresponding shaded section goes low. 2 6 10 REV
24.	P32	Dynamic lighting indication REPEAT • 3 • 7 • 11 • LED	• Four corresponding LEDs light one at a time in accordance with the scanning of Pφφ to Pφ3. As each switch is pressed, the corresponding shaded section goes low. 3 7 11 REPEAT

Terminal No.	Symbol	Name	Function/operation
25.	P33	Dynamic lighting indication B.S • [4] • [8] • [12]	Four corresponding LEDs light one at a time in accordance with the scanning of P$\phi\phi$ to Pϕ3. 
26.	P4 ϕ	FL counter Segment g	 — Number indication — Segment g (26) Segment a (36) Segment b (32) Segment c (31) Segment d (30) Segment e (28) Segment f (27) — Running indication — Segment g Segment e Segment c Segment d 5V — ON 0V — OFF
27.	P41	FL counter Segment f	
28.	P42	FL counter Segment e	
29.	P43	TIME	
30.	P5 ϕ	FL counter Segment d	
31.	P51	FL counter Segment c	
32.	P52	FL counter Segment b	Counter number changes when takeup reel table rotates two turns. Each segment of running indication changes when the reel table rotates a half turn. Waveforms change since dynamic lighting is used. •“min”, “sec”, and “:” are displayed when the TIME signal is given. 
36.	P53	FL counter Segment a	
33.	VDD	Power supply terminal	• Operative on 4.5 to 5.5 volts (typically 5.4 volts).
34.	VMM	Power supply terminal for the memory	• Operative on 4.5 to 5.5 volts (typically 5.4 volts).
35.	HLD $\overline{M}$	Power hold instruction terminal for the memory	• Operative on 4.5 to 5.5 volts (typically 5.4 volts).
37.	P6 ϕ	Reading of input switch state FWD REC INH	•“High” level when a tape not prepared with miserase prevention masking is loaded. •“Low” level with the cassette lid open.
38.	P61	Reading of input switch state REV REC INH	•“High” level when a tape not prepared with miserase prevention masking is loaded. •“Low” level with the cassette lid open.

Terminal No.	Symbol	Name	Function/operation
39.	P62	Reading of input switch state CAM A (S607)	
40.	P63	Reading of input switch state CAM B (S606)	• Input in switching-over from FWD PLAY to REV PLAY. 
41.	P7 ϕ	Reading of input switch state Half det. (S603)	• Goes “low” level when a cassette tape is loaded and the cassette lid is closed. • “High” level with the cassette lid open.
42.	P71	Leader tape det	• “Low” level pulses are generated between the leader tape section and the magnetic section. 
43.	P72	Detection of music intervals	• Goes low during a portion between music pieces (no signal portion).
44.	P73		• Non connection.
45.	P80	Muting for all amplifiers	• “High” level during FF, REW and STOP. • “Low” level during REC, PLAY and CUE/REV.
46.	P81	CUE/REVIEW MUTE	• “High” level pulse with CUE/REVIEW button pressed during PLAY. 
47.	P82	Drive motor CCW rotation command	• “High” level pulse in each mode in operational sequence REV PLAY → PAUSE → STOP → FOW PLAY. • During switching between REV PLAY → FOW PLAY. 
48.	P83	Drive motor CW rotation command	• “High” level pulse in each mode in operational sequence FOW PLAY → PAUSE → STOP → REV PLAY. • During switching between FWD PLAY → REV PLAY. 
49.	P9 ϕ	REC indication output	• “High” level concurrently with REC command. • In TIMER REC mode, “High” level just after power on. 
50.	P91	PAUSE indication output	• “High” level concurrently with PAUSE command. 


Terminal No.	Symbol	Name	Function/operation
51.	P92	Reel takeup torque selection and PLAY indication output	• "High" level during PLAY. • "Low" level during FF, REW and STOP.
52.	P93	DIRECTION indication output	• "Low" level during FORWARD. • "High" level during REVERSE.
53.	PA ϕ	Bias oscillation ON/OFF	• Goes to "Low" immediately after REC/PAUSE operation. • Remains in "Low" during REC/PLAY operation. • Goes to "Low" approximately 20msec after the STOP command is given.  REC • PAUSE mode
54.	PA1	REC MUTE	• "High" level pulse with REC MUTE button pressed during REC PLAY. 
55.	PA2	FF/REW motor rotation select (FF/REW motor CCW rotation command)	• "High" level during: - FWD PLAY - FWD F.F - REV REW
56.	PA4	FF/REW motor rotation select (FF/REW motor CW rotation command)	• "High" level during: - REV PLAY - REV F.F - FWD REW
57.	PB ϕ	Reel table rotation detection-1 (tape counter)	• Rotation pulses are generated according to the rotation speed of the take-up reel table in the FWD mode. • Two pulses are generated per reel table rotation.  Reel table rotation detection-1 (tape counter) Reel table rotation detection-2 (tape counter) Phase difference: approximately 90 degrees Phase difference: approximately 90 degrees Counterclockwise rotation of the reel table Clockwise rotation of the reel table
58.	PB1	Reel table rotation detection-2 (tape counter)	
59.	PB2	Output mute during power on	• Goes "high" level when power is on. • This terminal goes "low" level when terminal 17 goes "high" level. 
60.	PB3	Input switch reading Head rotation direction detection (S608)	• "High" level during FORWARD.


Terminal No.	Symbol	Name	Function/operation
61.	OSC2	Terminals for connecting the oscillator device of a clock	Generates oscillation at approximately 4MHz. 
62.	OSC1	Terminals for connecting the oscillator device of a clock	
63.	TC1	_____	Non connection.
64.	TC ϕ	_____	Non connection. 

NOTES (for Block diagram)


- S1-1, S1-2.....
Dolby-C IN/OUT switch (shown in OUT position).
- S2-1, S2-2.....
Dolby-B IN/OUT switch (shown in OUT position).
- S3-1, S3-2.....
dbx "Tape" IN/OUT switch (shown in OUT position).
- S4-1, S4-2.....
dbx "Disc" IN/OUT switch (shown in OUT position).
- S301.....
Power ON/OFF switch (shown in OFF position).
- S302.....
AC power voltage select switch.
- S401.....
Timer REC/PLAY switch (shown in Timer REC position).
- S402-1, S402-2.....
Mode select switch (⌚ / ⏮).
- S501.....
Direction switch (shown in OFF position).
- S502.....
Record switch (shown in OFF position).
- S503.....
F.F switch (shown in OFF position).
- S504.....
Rewind switch (shown in OFF position).
- S505.....
Play switch (shown in OFF position).
- S506.....
Pause switch (shown in OFF position).
- S507.....
Stop switch (shown in OFF position).
- S508.....
Auto-Rec mute switch (shown in OFF position).
- S509.....
Counter Reset switch (shown in OFF position).
- S510.....
Tape counter switch (shown in OFF position).
- S511.....
Time counter switch (shown in OFF position).
- S512.....
D.M.S. [1] switch (shown in OFF position).
- S513.....
D.M.S. [2] switch (shown in OFF position).
- S514.....
D.M.S. [3] switch (shown in OFF position).
- S515.....
D.M.S. [4] switch (shown in OFF position).
- S516.....
D.M.S. [5] switch (shown in OFF position).
- S517.....
D.M.S. [6] switch (shown in OFF position).
- S518.....
D.M.S. [7] switch (shown in OFF position).
- S519.....
D.M.S. [8] switch (shown in OFF position).
- S520.....
D.M.S. [9] switch (shown in OFF position).
- S521.....
D.M.S. [10] switch (shown in OFF position).
- S522.....
D.M.S. [12] switch (shown in OFF position).
- S523.....
D.M.S. [13] switch (shown in OFF position).
- S524.....
Blank Skip switch (shown in OFF position).
- S525.....
Repeat switch (shown in OFF position).
- S526.....
D.M.S. FWD/REV switch.
- S601.....
Auto tape select switch (for Metal tape).
- S602.....
Auto tape select switch (for CrO₂ tape).
- S603.....
Cassette half switch (shown in OFF position).
- S604.....
FWD Rec inhibit switch (shown in OFF position).
- S605.....
REV Rec inhibit switch (shown in OFF position).
- S606.....
FWD/REV changing switch (shown in OFF position).
- S607.....
Mode changing switch (shown in OFF position).
- S608.....
FWD/REV detection switch (shown in FWD position).


BLOCK DIAGRAM







SCHEMATIC DIAGRAM (for Main/FL Meter Section)





SCHEMATIC DIAGRAM (for Main/FL Meter Section)





NOTES:

- S1-1, S1-2.....Dolby-C IN/OUT switch (shown in OUT position).
- S2-1, S2-2.....Dolby-B IN/OUT switch (shown in OUT position).
- S3-1, S3-2.....dbx "Tape" IN/OUT switch (shown in OUT position).
- S4-1, S4-2.....dbx "Disc" IN/OUT switch (shown in OUT position).
- S301.....Power ON/OFF switch (shown in OFF position).
- S302.....AC power voltage select switch.
- S401.....Timer REC/PLAY switch (shown in Timer REC position).
- S402-1, S402-3.....Mode select switch (○ / ➡).
- S501.....Direction switch (shown in OFF position).
- S502.....Record switch (shown in OFF position).
- S503.....F.F switch (shown in OFF position).
- S504.....Rewind switch (shown in OFF position).
- S505.....Play switch (shown in OFF position).
- S506.....Pause switch (shown in OFF position).
- S507.....Stop switch (shown in OFF position).
- S508.....Auto-Rec mute switch (shown in OFF position).
- S509.....Counter Reset switch (shown in OFF position).
- S510.....Tape counter switch (shown in OFF position).
- S511.....Time counter switch (shown in OFF position).
- S512.....D.M.S. 1 switch (shown in OFF position).
- S513.....D.M.S. 2 switch (shown in OFF position).
- S514.....D.M.S. 3 switch (shown in OFF position).
- S515.....D.M.S. 4 switch (shown in OFF position).
- S516.....D.M.S. 5 switch (shown in OFF position).
- S517.....D.M.S. 6 switch (shown in OFF position).
- S518.....D.M.S. 7 switch (shown in OFF position).
- S519.....D.M.S. 8 switch (shown in OFF position).
- S520.....D.M.S. 9 switch (shown in OFF position).
- S521.....D.M.S. 10 switch (shown in OFF position).
- S522.....D.M.S. 11 switch (shown in OFF position).
- S523.....D.M.S. 12 switch (shown in OFF position).
- S524.....Blank Skip switch (shown in OFF position).
- S525.....Repeat switch (shown in OFF position).
- S526.....D.M.S. FWD/REV switch.
- S601.....Auto tape select switch (for Metal tape).
- S602.....Auto tape select switch (for CrO₂ tape).
- S603.....Cassette half switch (shown in OFF position).
- S604.....FWD Rec inhibit switch (shown in OFF position).
- S605.....REV Rec inhibit switch (shown in OFF position).
- S606.....FWD/REV changing switch (shown in OFF position).
- S607.....Mode changing switch (shown in OFF position).
- S608.....FWD/REV detection switch (shown in FWD position).
- VR1, 2.....Playback gain adjustment VR.
- VR3, 4.....Overall gain adjustment VR.
- VR5, 6.....Input level controls.
- VR7.....Balance control.
- VR8.....FL meter adjustment VR (-40dB indication).
- VR9, 10.....Output level controls.
- VR11.....Attack recovery time adjustment VR.
- VR301, 302.....Bias current adjustment VR.
- VR303.....Photo sensor sensitivity adjustment VR.
- VR305, 306.....Erase current adjustment VR.
- VR501.....FL meter adjustment VR (0dB indication).
- VR601.....Takeup torque adjustment VR.
- L1, L2.....Skewing Network.
- L3, L4.....Bias Trap Coil.
- L5, L6.....Peaking Coil.
- L7.....Check Coil.
- L301, L302.....Bias Oscillation Coil.
- L401.....Choke Coil.
- L601—L604.....Choke Coil.
- MPX1, 2.....Multiplex Filter.
- Resistance are in ohms (Ω), 1/4 watt unless specified otherwise.
1K = 1,000(Ω), 1M = 1,000k(Ω)
- Capacity are in micro-farads (μF) unless specified otherwise.
- The mark (▼) shows test point. e.g. ▼ = Test point 1.
- All voltage values shown in circuitry are under no signal condition and playback mode with volume control at minimum position otherwise specified.
- ().....Voltage values at record mode.
- dbx/PLAY.....Voltage values at dbx encode mode.
- dbx/TAPE.....Voltage values at dbx encode or decode mode.
- CrO₂.....Voltage values at CrO₂ tape mode.
- Metal.....Voltage values at Metal tape mode.
- Stop.....Voltage values at Stop mode.
- C/R.....Voltage values at CUE/REV mode.
- FF/REW.....Voltage values at FF/REW mode.
- REC MUTE.....Voltage values at AUTO REC MUTE mode.
- 70μs.....Voltage values at CrO₂ or Metal tape mode.
- NR IN.....Voltage value at which the noise reduction switch is turned on.
- CFM.....Voltage value at which the test tape QZZCFM (315Hz/0dB) is played.
- TAPE END.....Voltage at the end of the cassette tape.
- For measurement use VTVM.
- (●) indicates B+ (bias).
- (■) indicates B- (bias).
- (→) indicates the flow of the playback signal. (NR out).
- (⇄) indicates the flow of the recording signal. (NR out).

- Important safety notice
Components identified by Δ mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.
- Described in the schematic diagram are two types of numbers; the supply parts numbers and production parts number for transistors and diodes. One type of number is used for supply parts number and production parts number when they are identical.
- e.g. Q1
2SC1844(E,F).....Production parts number
[2SC1844E].....Supply parts number
D212
1S2473T77.....Production parts number
[MA161].....Supply parts numbers
- The supply parts number is described alone in the replacement parts list.
- This schematic diagram may be modified at any time with the development of new technology.


- * Output level control...MAX
- * Input level control ...MAX
- * Balance control Center

SPECIFICATIONS


Playback S/N ratio * Test tape...QZZCFM	Greater than 45dB
Overall distortion * Test tape ...QZZCRA for Normal ...QZZCRX for CrO ₂ ...QZZCRZ for Metal	Less than 4%
Overall S/N ratio * Test tape...QZZCRA	Greater than 43dB (without NAB filter)

EQUIVALENT CIRCUIT

IC501: AN6870N



SCHEMATIC DIAGRAM (for Mechanism/Mechanism Control Section)



SCHEMATIC DIAGRAM (for Mechanism/Mechanism Control Section)

types of numbers; the supply
for transistors and diodes.
number and production parts

number
number
the replacement parts list.
modified at any time
ology.

control...MAX
control ...MAX
control Center

greater than 45dB

less than 4%

more than 43dB
(without NAB filter)

MIT

OUT 23 OUT A (+18dB)

OUT 22 OUT B (+12dB)

OUT 21 OUT C (+8dB)

OUT 20 OUT D (+6dB)

OUT 1 (-4 dB)


OUT 14 OUT J (- 6dB)

OUT 0 (-20dB)


OUT P (-24 dB)

OUT ⑦ OUT Q (-30dB)

OUT 6 OUT R (-40dB)



SCHEMATIC DIAGRAM (for Mechanism/Mechanism Control Section)



ELECTRICAL PARTS LIST

NOTES:

RESISTORS

ERD.....Carbon
ERG Metal-oxide
ERS.....Metal-oxide
ERO Metal-film
ERX.....Metal-film
ERQ Fuse type metallic
ERC.....Solid
ERF.....Cement

CAPACITORS

ECBA	Ceramic
ECG□	Ceramic
ECK□	Ceramic
ECO□	Ceramic
ECF□	Ceramic
ECQM	Polyester film
ECQE	Polyester film
ECQF	Polypropylene
ECED	Electrolytic
ECEDN	...Non polar electrolytic
ECQS	Polystyrene
EC□	Tantalum
QCS	Tantalum

REPLACEMENT PARTS LIST

Important safety notice
Components identified by  mark have special characteristics important for safety.
When replacing any of these components, use only manufacturer's specified parts.

Ref. No.	Part No.	Part Name & Description
<u>CONNECTORS</u>		
CN 1	QJT1090	Check Pin
CN 2	QJT1054	Contact
CN 3	QJS1920TN	2 Pin Socket
CN 4	QJP1920TN	2 Pin Plug
CN 5	QJS1921TN	3 Pin Socket
CN 6	QJP1921TN	3 Pin Plug
CN 7	QJS1922TN	6 Pin Socket
CN 8	QJP1922TN	6 Pin Plug
CN 9	QJS1987S	Jumper Socket (4 Pin)
CN 10	QJS1961S	Jumper Socket (5 Pin)
CN 11	QJS1993S	Jumper Socket (6 Pin)
CN 12	QJS1962S	Jumper Socket (7 Pin)
CN 13	QJS1983S	Jumper Socket (8 Pin)
CN 14	QJS1994S	Jumper Socket (6 Pin/Type-L)
CN 15	QJS2004S	Jumper Socket (10 Pin/Type-L)

Ref. No.	Part No.	Ref. No.	Part No.
RESISTORS		R 45, 46	ERD25TJ183
R 1, 2	ERD25TJ273	R 47, 48	ERD25FJ181
R 3, 4	ERD25TJ394	R 49, 50, 51, 52	
R 5, 6	ERD25FJ102		ERD25FJ103
R 7, 8	ERD25TJ1273	R 53, 54	ERD25FJ101
R 9, 10	ERD25FJ102	R 55, 56	ERD25FJ512
R 11, 12	ERD25FJ472	R 57, 58	ERD25FJ102
R 13, 14	ERD25TJ224	R 59, 60	ERD25TJ224
R 15, 16	ERD25FJ100	R 61, 62	ERD25TJ683
R 17, 18	ERD25FJ472	R 63, 64	ERD25FJ512
R 19	ERD25FJ561	R 65, 66	ERD25FJ222
		R 67, 68	ERD25TJ823
R 20	ERD25TJ223	R 69, 70	ERD25FJ472
R 21, 22	ERD25TJ563	R 71, 72	ERD25TJ123
R 23, 24	ERD25FJ101	R 73, 74	ERD25TJ473
R 25, 26	ERD25FJ102	R 75, 76	ERD25TJ753
R 27, 28	ERD25FJ181	R 77, 78	ERD25TJ334
R 29, 30	ERD25TJ334	R 79, 80, 81, 82	
R 31, 32	ERD25FJ682		ERD25TJ394
R 33, 34	ERD25FJ562		
R 35, 36	ERD25TJ225	R 83, 84	ERD25TJ334
R 37, 38	ERD25TJ104	R 85	ERD25FJ222
		R 86	ERD25FJ472
R 39, 40	ERD25FJ103	R 87	ERD25FJ222
R 41, 42	ERD25FJ472	R 88	ERD25FJ472
R 43, 44	ERD25FJ272	R 91, 92	ERD25TJ153

Ref. No.	Part No.	Ref. No.	Part No.
R 93, 94	ERD25FJ102	R 311	ERD25FJ222
R 95, 96, 97, 98		R 312	ERD25FJ562
	ERD25TJ104	R 313	ERD25TJ473
R 99, 100	ERD25FJ332	R 316, 317	
R 101, 102, 103, 104	ERD25TJ223	[N] Δ	ERX12ANJ3R9
		[For Asia, Latin America	
		Middle East and Africa	
		areas.]	
R 105, 106	ERD25FJ822	[D][B][A] Δ	ERQ12HJ3R9
R 107, 108	ERD25TJ333	[For All European and	
R 109, 110	ERD25TJ244	Australia.]	
R 111, 112	ERD25TJ154		
R 113, 114	ERD25FJ472	R 318, 319	
R 115, 116	ERD25TJ333	Δ	ERD25FJ681
R 117, 118	ERD25FJ682	R 320 Δ	ERX2ANJ4R7
R 119, 120, 121, 122		R 321 Δ	ERD25FJ102
	ERD25FJ332	R 322, 323	
R 123, 124	ERD25TJ223	[D][B][A]	ERD25TJ153
R 125, 126	ERD25FJ472	[For All European and	
		Australia.]	
R 127, 128	ERD25TJ153	R 324	ERD25TJ683
R 129	ERD25FJ472		
R 130	ERD25TJ274	R 325	ERD25FJ472
R 131, 132	ERD25FJ102	R 326, 327	ERD25FJ103
R 133, 134	ERD25FJ103	R 328	ERD25FJ272
R 135, 136	ERD25FJ151	R 329	ERD25FJ101
R 137, 138	ERD25FJ472	R 330	ERD25FJ103
R 139, 140	ERD25TJ153	R 331	ERD25TJ104
R 141	ERD25FJ103	R 332	ERD25TJ124
R 142	ERD25TJ104	R 333	ERD25FJ221
		R 334	ERD25FJ102
		R 335	ERD25TJ184
R 143	ERD25FJ102		
R 144	ERD25TJ473	R 336	ERD25TJ104
R 145	ERD25FJ222	R 337	ERD25TJ563
R 147	ERD25TJ153	R 338 [N]	ERD25FJ180
R 148	ERD25FJ151	[For Asia, Latin America,	
R 149	ERD25FJ102	Middle East and Africa	
R 150, 151		areas.]	
[N] ERD25FJ390		[D][B][A]	ERD2FCG180
[For Asia, Latin America,		[For All European and	
Middle East and Africa		Australia.]	
areas.]			
[D][B][A]	ERD2FCG390	R 339	ERD25FJ120
[For All European and		R 340	ERD25FJ103
Australia.]		R 341	ERD25FJ471
		R 345	ERD25FJ103
R 152	ERD25FJ103	R 349	ERD25FJ103
R 153, 154	ERD25TJ104	R 351	ERD25FJ103
R 155, 156	ERD25FJ102	R 352	ERD25FJ562
R 157, 158	ERD25TJ123		
R 159, 160, 161, 162		R 353	ERD25TJ473
	ERD25TJ225	R 354	ERD25FJ103
R 163, 164	ERD25FJ182	R 355	ERD25FJ472
R 165, 166	ERD25FJ682	R 356, 357, 358, 359, 360, 361	
R 167, 168	ERD25FJ102		ERD25FJ103
R 169, 170	ERD25FJ390	R 362	ERD25TJ563
R 171, 172	ERD25FJ821	R 363	ERD25FJ682
R 173, 174	ERD25FJ272	R 364	ERD25TJ563
R 175, 176	ERD25FJ103	R 365	ERD25TJ223
R 177, 178	ERD25FJ222	R 366	ERD25TJ154
		R 367	ERD25TJ104
R 179, 180	ERD25FJ272		
R 181, 182	ERD25FJ821	R 368	ERD25FJ103
R 183, 184	ERD25FJ101	R 369	ERD25FJ332
R 185, 186	ERD25TJ473	R 370	ERD25TJ333
R 187 [N]	ERD25FJ220	R 371	ERD25TJ563
[For Asia, Latin America,		R 372, 373	ERD25FJ103
Middle East and Africa		R 374	ERD25FJ221
areas.]		R 375, 376	ERD25FJ681
[D][B][A]	ERD25FCG270	R 377	ERD25FJ102
[For All European and		R 378, 379	
Australia.]		[N]	ERD25FJ470
		[For Asia, Latin America,	
R 189, 190	ERD25FJ680	Middle East and Africa	
R 201	ERD25FJ1R0	areas.]	
R 202	ERD25FJ100	[D][B][A]	ERD2FCG470
R 203, 204	ERD25FJ562	[For All European and	
R 205	ERD25FJ100	Australia.]	
R 206 [N]	ERD25FJ100	R 380	ERD25FJ103
[For Asia, Latin America,			
Middle East and Africa			
areas.]			
[D][B][A]	ERD2FCG100	R 381	ERD25TJ105
[For All European and		R 382	ERD25FJ103
Australia.]		R 383	ERD25FJ472
		R 384	ERD25FJ332
R 207	ERD25FJ332	R 385	ERD25FJ103
R 209, 210	ERD25FJ222	R 386	ERD25TJ473
R 213, 214	ERD25TJ473	R 387	ERD25TJ273
R 216	ERD25FJ103	R 388	ERD25FJ222
R 302	ERD25FJ100	R 389	ERD25TJ683
R 303, 304	ERD25FJ562	R 390	ERD25FJ101
R 305	ERD25FJ100		
R 306 [N]	ERD25FJ100	R 391	ERD25FJ682
[For Asia, Latin America,		R 392	ERD25FJ471
Middle East and Africa		R 393	ERD25FJ102
areas.]		R 394	ERD25FJ682
[D][B][A]	ERD2FCG100	R 395	ERD25TJ183
[For All European and		R 396, 397	ERD25FJ103
Australia.]		R 398, 399	ERD25FJ472
R 307	ERD25FJ222	R 402	ERD25TJ223
		R 403	ERD25FJ562
		R 404	ERD25TJ223
R 310	ERD25FJ332		

Ref. No.	Part No.	Ref. No.	Part No.
R 407	ERD25TJ103	C 61, 62	ECQM1H333JZ
R 408, 409,	410, 411		
	ERD25FJ682	C 63, 64	ECQM1H224JZ
R 412, 413,	414, 415	C 65	ECQM1H822JZ
	ERD25FJ151	C 66	ECEA1EN3R3
R 416	ERD25FJ562	C 67, 68	ECEA50ZR22
R 420	ERD25FJ562	C 69, 70, 71, 72	ECQM1H104JZ
R 424	ERD25FJ562		
R 428	ERD25FJ562	C 73, 74, 75, 76	ECQM1H332JZ
R 432	ERD25FJ471		
R 437, 438,	439	C 77, 78	ECCD1H331K
	ERD25FJ681	C 79, 80	ECQM1H223JZ
R 440	ERD25FJ471	C 81, 82	ECCD1H471K
R 441	ERD25FJ562	C 83, 84	ECEA50MR68R
R 442, 443, 444, 445, 446, 447,			
448, 449	ERD25TJ103	C 85, 86	ECEA1CS100
R 450, 451,	452, 453	C 87, 88	ECQM1H472JZ
	ERD25FJ821	C 89, 90	ECEA16Z10
R 454, 455, 456, 457, 458, 459,		C 91, 92	ECQM1H333JZ
460, 461	ERD25FJ562	C 93, 94	ECEA50MR33R
R 462	ERD25TJ223	C 95, 96	ECEA0JS470
R 463	ERD25FJ562	C 97, 98	ECCD1H391J
R 464	ERD25FJ103	C 99, 100	ECQM1H223JZ
R 503, 504	ERD25TJ104	C 101	ECEA1CS100
R 505, 506		C 102, 103, 104	ECEA50Z1
	[N] ERD25TJ181		
	[For Asia, Latin America, Middle East and Africa areas.]	C 105	ECEA1AS471
	[D][B][A] ERG12ANJ271	C 106	ECEA0JS331
	[For all European and Australia.]	C 107, 108	ECQM1CS100
R 507	ERD25FJ182	C 109, 110	ECKD2H121KB
		C 111, 112	ECKD1H561KB
R 508	ERD25FJ471	C 113, 114	ECEA50ZR33
R 509	ERD25TJ684	C 115, 116	ECEA1CN100
R 510 [N]	ERD25TJ181	C 117, 118	ECQM1H273JZ
	[For Asia, Latin America, Middle East and Africa areas.]	C 119, 120	ECFDD472KVY
	[D][B][A] ERG1ANJ181	C 125, 126, 127, 128	ECEA50Z1
	[For all European and Australia.]		
R 511	ERD25FJ472	C 133, 134	ECFDD223KXY
R 512, 513, 523	ERD25FJ103	C 137	ECEA1ES4R7
	ERD25FJ103	C 138	ECEA0JS470
R 524, 525	ERD25TJ473	C 139	ECKD1H223ZF
R 526	ERD25FJ103	C 301, 302	ECCD1H221KD
R 601	ERD25TJ181	C 303	ECQP1682JZ
		C 304	ECFDD153KXY
		C 305	ECFDD822KXY
		C 306, 307	ECEA1ES220
		C 308, 309	△ ECKD1H223ZF
VARIABLE RESISTORS			
VR 1, 2	QVNB3A00B223	C 310, 311	ECEA1CS331
VR 3, 4	QVNB3A00B103	C 312	ECKD1H223ZF
VR 5, 6	QVBP1PUA54	C 314 △	ECEA1CS332
VR 7	QVAL5KUG15	C 315 △	ECEA1CS222
VR 8	QVNB3A00B222	C 316 △	ECEA1CS332
VR 9, 10	QVBF1PUA14	C 317	
VR 11	QVNB3A00B222	[D][B][A] ECEA1CS330	
VR 301, 302	QVNB3A00B474	[For all European and Australia.]	
VR 303, 305, 306		C 318	ECEA1CS100
	QVNB3A00B103	C 319	ECQM1H394JZ
VR 501	QVNB3A00B223	C 320	ECEA1ES4R7
		C 324	ECEA1CS100
VR 601	EVNK4AA00B22		
CAPACITORS		C 325	ECEA1CS221
C 1, 2	ECEA50Z1	C 326, 327	ECEA1CS330
C 3, 4	ECQM1H224JZ	C 328	ECEA50Z1
C 5, 6	ECEA1ES4R7	C 329	ECQM1H104JZ
C 7, 8	ECCD1H820K	C 330	ECQM1H474JZ
C 9, 10	ECEA50Z1	C 331	ECEA1CS100
C 11, 12	ECKD1H331KB	C 332	ECEA1ES4R7
C 13, 14	ECEA0JS101	C 333	ECEA1ES220
C 17, 18	ECQM1H103JZ	C 334	ECQM1H102JZ
C 19, 20	ECKD1H331KB	C 335	ECEA0JS101
C 21, 22	ECFDD152KVY		
C 23, 24	ECFDD122KVY	C 336	ECEA1ES4R7
C 25, 26	ECEA1ES4R7	C 337	ECQP1333JZ
C 27, 28	ECKD1H681K	C 338	ECFDD153KXY
C 29, 30	ECEA50Z1	C 339	ECFDD822KVY
C 31, 32	ECQM1H683JZ	C 340	ECEA1ES101
C 33, 34	ECQM1H154JZ	C 341	ECEA1CS101
C 35, 36	ECEA1ES4R7	C 342	ECEA1CS100
C 37, 38	ECQM1H103JZ	C 343	△ ECEA1CS222
C 39, 40	ECQM1H333JZ	C 344	ECQV1H104JZ
C 41, 42	ECQM1H472JZ	C 345 △	ECQV2A103MF
C 43, 44	ECEA1CS100		
C 45, 46	ECQM1H472JZ	C 401	ECCD1H101KC
C 47	ECFDD103KXY	C 402	ECCD1H330KC
C 48	ECEA1AS101	C 404	ECEA1HS010
C 49, 50	ECEA1CS100	C 405	ECEA1CS100
C 51, 52	ECEA1ES4R7	C 409	ECEA1HSR47
C 53, 54	ECQM1H473JZ	C 410	ECQM1H104JZ
C 55, 56	ECQM1H333JZ	C 501, 502	ECEA1ES4R7
C 57, 58, 59, 60		C 505	ECFDD393KXD
	ECQM1H104JZ	C 506	ECEA1CS100
COMBINATION PARTS			
Z 1, 2	EXRP152K473		


Ref. No.	Part No.	Ref. No.	Part No.
Z 3, 4	EXRP220K124	D 331, 332	MA1047
Z 5, 6	EXRP181K153	D 333, 334	MA161
Z 301	EXRP470K683	D 335	LD702DU
Z 401, 402	EXBEQ4272K	D 336, 337	MA161
Z 403	EXBEQ4562K	D 338	MA1056
Z 404	EXBEQ44102K	D 339	MA161
Z 405	EXBEQ4272K	D 340	MA1062
Z 406, 407	EXBEQ4563K	D 401, 402, 403, 404, 405, 406, 407	MA161
Z 408	EXBEQ4272K	D 409	MA161
Z 409	EXBEQ4472K	D 410	MA1120
Z 410	EXFP4103ZW		
TRANSISTORS		D 411, 412, 413, 414, 415, 416, 417, 418, 419, 420, 421, 422, 423, 424, 425, 426, 427, 428, 429, 430, 431, 432, 433, 434, 435, 436, 437, 438, 439, 440, 441, 442, 443, 444, 445, 446, 447, 448, 449, 450, 451, 452, 453, 454, 455, 456, 457, 458, 459, 460, 461, 462, 463, 464, 465, 466, 467, 468, 469, 470, 471, 472, 473, 474, 475, 476, 477, 478, 479, 480, 481, 482, 483, 484, 485, 486, 487, 488, 489, 490, 491, 492, 493, 494, 495, 496, 497, 498, 499, 500, 501, 502, 503, 504, 505, 506, 507, 508, 509, 510, 511, 512, 513, 514, 515, 516, 517, 518, 519, 520, 521, 522, 523, 524, 525, 526, 527, 528, 529, 530, 531, 532, 533, 534, 535, 536, 537, 538, 539, 540, 541, 542, 543, 544, 545, 546, 547, 548, 549, 550, 551, 552, 553, 554, 555, 556, 557, 558, 559, 560, 561, 562, 563, 564, 565, 566, 567, 568, 569, 570, 571, 572, 573, 574, 575, 576, 577, 578, 579, 580, 581, 582, 583, 584, 585, 586, 587, 588, 589, 590, 591, 592, 593, 594, 595, 596, 597, 598, 599, 600, 601, 602, 603, 604, 605, 606, 607, 608, 609, 610, 611, 612, 613, 614, 615, 616, 617, 618, 619, 620, 621, 622, 623, 624, 625, 626, 627, 628, 629, 630, 631, 632, 633, 634, 635, 636, 637, 638, 639, 640, 641, 642, 643, 644, 645, 646, 647, 648, 649, 650, 651, 652, 653, 654, 655, 656, 657, 658, 659, 660, 661, 662, 663, 664, 665, 666, 667, 668, 669, 670, 671, 672, 673, 674, 675, 676, 677, 678, 679, 680, 681, 682, 683, 684, 685, 686, 687, 688, 689, 690, 691, 692, 693, 694, 695, 696, 697, 698, 699, 700, 701, 702, 703, 704, 705, 706, 707, 708, 709, 710, 711, 712, 713, 714, 715, 716, 717, 718, 719, 720, 721, 722, 723, 724, 725, 726, 727, 728, 729, 730, 731, 732, 733, 734, 735, 736, 737, 738, 739, 740, 741, 742, 743, 744, 745, 746, 747, 748, 749, 750, 751, 752, 753, 754, 755, 756, 757, 758, 759, 760, 761, 762, 763, 764, 765, 766, 767, 768, 769, 770, 771, 772, 773, 774, 775, 776, 777, 778, 779, 780, 781, 782, 783, 784, 785, 786, 787, 788, 789, 790, 791, 792, 793, 794, 795, 796, 797, 798, 799, 800, 801, 802, 803, 804, 805, 806, 807, 808, 809, 810, 811, 812, 813, 814, 815, 816, 817, 818, 819, 820, 821, 822, 823, 824, 825, 826, 827, 828, 829, 830, 831, 832, 833, 834, 835, 836, 837, 838, 839, 840, 841, 842, 843, 844, 845, 846, 847, 848, 849, 850, 851, 852, 853, 854, 855, 856, 857, 858, 859, 860, 861, 862, 863, 864, 865, 866, 867, 868, 869, 870, 871, 872, 873, 874, 875, 876, 877, 878, 879, 880, 881, 882, 883, 884, 885, 886, 887, 888, 889, 890, 891, 892, 893, 894, 895, 896, 897, 898, 899, 900, 901, 902, 903, 904, 905, 906, 907, 908, 909, 910, 911, 912, 913, 914, 915, 916, 917, 918, 919, 920, 921, 922, 923, 924, 925, 926, 927, 928, 929, 930, 931, 932, 933, 934, 935, 936, 937, 938, 939, 940, 941, 942, 943, 944, 945, 946, 947, 948, 949, 950, 951, 952, 953, 954, 955, 956, 957, 958, 959, 960, 961, 962, 963, 964, 965, 966, 967, 968, 969, 970, 971, 972, 973, 974, 975, 976, 977, 978, 979, 980, 981, 982, 983, 984, 985, 986, 987, 988, 989, 990, 991, 992, 993, 994, 995, 996, 997, 998, 999, 1000	
Q 1, 2, 3	2SD1011		
Q 4	2SB1036		
Q 5, 6	2SD1450		
Q 7, 8	2SK330GRY		
Q 9, 10, 11, 12	2SD1450		
Q 13, 14, 15, 16, 17, 18, 19, 20, 21, 22	2SC3311		
Q 23, 24	2SD1011		
Q 25, 26, 27, 28	2SC3311		
Q 29, 30	2SA1115		
Q 31, 32	2SK330GRY		
Q 33, 34	2SJ105GR		
Q 35, 36	2SD1450		
Q 37, 38	2SA1115		
Q 39, 40, 41, 42	2SC3311		
Q 301, 302	2SD592		
Q 303	2SA719		
Q 304	2SA1115		
Q 305	UN4211TA		
Q 306	2SD1265OP		
Q 307	2SB941P		
Q 308	2SD1275		
Q 309	[D][B][A] 2SC3311 [For all European and Australia.]		
Q 310, 311, 312, 313	2SC3311		
Q 314	2SA1115		
Q 315	2SC1383		
Q 316	UN4211TA		
Q 317	2SC3311		
Q 318, 319, 320, 321, 322	2SA1115		
Q 323	2SD592		
Q 324	2SA719		
Q 325, 326	2SA1115		
Q 327	2SC3311		
Q 328	2SA1115		
Q 329, 330	2SC3311		
Q 401, 402, 403, 404, 405, 406, 407, 408, 409, 410	2SC2603		
Q 412, 413, 414, 415, 416, 417	2SC2603		
Q 418	UN4111TA		
Q 419	2SC2603		
Q 420	UN4111TA		
Q 421	2SC2603		
Q 422	UN4111TA		
Q 423	2SC2603		
Q 424	UN4111TA		
Q 425	2SC2603		
Q 426	2SD592		
Q 427	2SC2603		
Q 428, 429, 430, 431, 432, 433, 434, 435	2SA1115		
Q 501	2SC3311		
Q 502	2SA1115		
Q 508, 509	2SC2603		
Q 510	2SA1115		
DIODES & RECTIFIERS			
D 1	MA161		
D 3, 4	MA161		
D 5	MA1056		
D 6	MA161		
D 301	MA1220M		
D 302	MA1075		
D 303, 304, 305, 306, 307	Δ SM112		
D 308	MA161		
D 309	SM112		
D 310, 311, 312, 314, 315, 316, 317, 318, 319, 320, 321, 322, 323, 324, 325, 326, 327, 328, 329, 330	MA161		
D 331, 332	MA1047		
D 333, 334	MA161		
D 335	LD702DU		
D 336, 337	MA161		
D 338	MA1056		
D 339	MA161		
D 340	MA1062		
D 401, 402, 403, 404, 405, 406, 407	MA161		
D 409	MA161		
D 410	MA1120		
D 411, 412, 413, 414, 415, 416, 417, 418, 419, 420, 421, 422, 423, 424, 425, 426, 427, 428, 429, 430, 431, 432, 433, 434, 435, 436, 437, 438, 439, 440, 441, 442, 443, 444, 445, 446, 447, 448, 449, 450, 451, 452, 453, 454, 455, 456, 457, 458, 459, 460, 461, 462, 463, 464, 465, 466, 467, 468, 469, 470, 471, 472, 473, 474, 475, 476, 477, 478, 479, 480, 481, 482, 483, 484, 485, 486, 487, 488, 489, 490, 491, 492, 493, 494, 495, 496, 497, 498, 499, 500, 501, 502, 503, 504, 505, 506, 507, 508, 509, 510, 511, 512, 513, 514, 515, 516, 517, 518, 519, 520, 521, 522, 523, 524, 525, 526, 527, 528, 529, 530, 531, 532, 533, 534, 535, 536, 537, 538, 539, 540, 541, 542, 543, 544, 545, 546, 547, 548, 549, 550, 551, 552, 553, 554, 555, 556, 557, 558, 559, 560, 561, 562, 563, 564, 565, 566, 567, 568, 569, 570, 571, 572, 573, 574, 575, 576, 577, 578, 579, 580, 581, 582, 583, 584, 585, 586, 587, 588, 589, 590, 591, 592, 593, 594, 595, 596, 597, 598, 599, 600, 601, 602, 603, 604, 605, 606, 607, 608, 609, 610, 611, 612, 613, 614, 615, 616, 617, 618, 619, 620, 621, 622, 623, 624, 625, 626, 627, 628, 629, 630, 631, 632, 633, 634, 635, 636, 637, 638, 639, 640, 641, 642, 643, 644, 645, 646, 647, 648, 649, 650, 651, 652, 653, 654, 655, 656, 657, 658, 659, 660, 661, 662, 663, 664, 665, 666, 667, 668, 669, 670, 671, 672, 673, 674, 675, 676, 677, 678, 679, 680, 681, 682, 683, 684, 685, 686, 687, 688, 689, 690, 691, 692, 693, 694, 695, 696, 697, 698, 699, 700, 701, 702, 703, 704, 705, 706, 707, 708, 709, 710, 711, 712, 713, 714, 715, 716, 717, 718, 719, 720, 721, 722, 723, 724, 725, 726, 727, 728, 729, 730, 731, 732, 733, 734, 735, 736, 737, 738, 739, 740, 741, 742, 743, 744, 745, 746, 747, 748, 749, 750, 751, 752, 753, 754, 755, 756, 757, 758, 759, 760, 761, 762, 763, 764, 765, 766, 767, 768, 769, 770, 771, 772, 773, 774, 775, 776, 777, 778, 779, 780, 781, 782, 783, 784, 785, 786, 787, 788, 789, 790, 791, 792, 793, 794, 795, 796, 797, 798, 799, 800, 801, 802, 803, 804, 805, 806, 807, 808, 809, 810, 811, 812, 813, 814, 815, 816, 817, 818, 819, 820, 821, 822, 823, 824, 825, 826, 827, 828, 829, 830, 831, 832, 833, 834, 835, 836, 837, 838, 839, 840, 841, 842, 843, 844, 845, 846, 847, 848, 849, 850, 851, 852, 853, 854, 855, 856, 857, 858, 859, 860, 861, 862, 863, 864, 865, 866, 867, 868, 869, 870, 871, 872, 873, 874, 875, 876, 877, 878, 879, 880, 881, 882, 883, 884, 885, 886, 887, 888, 889, 890, 891, 892, 893, 894, 895, 896, 897, 898, 899, 900, 901, 902, 903, 904, 905, 906, 907, 908, 909, 910, 911, 912, 913, 914, 915, 916, 917, 918, 919, 920, 921, 922, 923, 924, 925, 926, 927, 928, 929, 930, 931, 932, 933, 934, 935, 936, 937, 938, 939, 940, 941, 942, 943, 944, 945, 946, 947, 948, 949, 950, 951, 952, 953, 954, 955, 956, 957, 958, 959, 960, 961, 962, 963, 964, 965, 966, 967, 968, 969, 970, 971, 972, 973, 974, 975, 976, 977, 978, 979, 980, 981, 982, 983, 984, 985, 986, 987, 988, 989, 990, 991, 992, 993, 994, 995, 996, 997, 998, 999, 1000			
		Ref. No.	Part No.
		MULTIPLEXERS	
		MPX 1, 2 QLM9Z10K	
		L 1, 2	ELM7Q306A
		L 3, 4	QLQX0343KWA
		L 5, 6	QLQX2722D
		L 7	QLQX1012DT
		L 301, 302	QLB0198
		L 401	QLQX1012DT
		L 601, 602, 603, 604	ELEH101KA
		TRANSISTORS	
		T 301	[D][B] Δ QLP476ELX [For all European areas.]
		[A][N] Δ QLP488ELX	[For Australia, Asia, Latin America and Africa areas.]
		F 1 [N] Δ XBA2E03NS5	[For Asia, Latin America and Africa areas.]
		[D][B][A] Δ XBAQ100027	[For all European and Africa areas.]
		F 2 [D][B][A] Δ XBAQ100027	[For all European and Africa areas.]
		SWITCHES	
		S 1, 2, 3, 4	QSW2240
		S 301 Δ	QSW1127
		S 302 Δ	QSR1407
		S 401	QSS1306
		S 402	QSW2241
		S 501	SSG13
		S 502, 503, 504	QSWY207

	Ref. No.	Part No.
	D 622, 623, 624, 625, 626 QVDLS0050 (With ATS/Direction Circuit Board)	
	<u>INTEGRATED CIRCUITS</u>	
06,	IC 1 M5218L	
	IC 2 M5220L	
	IC 3, 4 NE654N	
	IC 5, 6 NE652N	
	IC 7 AN6258	
16,	IC 8 AN6291	
	IC 9, 10 AN6203	
	IC 11, 12 M5218L	
06,	IC 301, 302 M5218L	
12,	IC 401 MN1564RME	
	IC 402 AN6271	
	IC 403 AN6270	
	IC 404, 405 DN6838	
	IC 501 AN6870N	
	IC 502, 503 AN6280	
	<u>IC PROTECTOR</u>	
28, 34	F 601 QRUF10WH	
	<u>CERAMIC RESONATOR</u>	
LED)	X 401 EF0A4R0M01A	

Part Name & Description	Ref. No.
<u>LEX FILTERS</u>	S 505,
M.P.X Coil	S 508
<u>COILS</u>	S 509,
Skewing Network	
Bias Trap Coil	S 512
Peaking Coil	
Choke Coil	S 513
Bias Oscillation Coil	S 514
Choke Coil	S 515
Choke Coil	S 516
<u>FORMER</u>	S 517
AC Power Transformer	S 518
s.]	
AC Power Transformer	S 519
Latin America, Middle East	S 520
<u>FUSES</u>	S 521
Fuse (300mA)	
a, Middle East and Africa	S 522
	S 523
Fuse (T 1 A)	
Australia.]	S 524
	S 525
Fuse (T 1 A)	S 526
Australia.]	S 601,
<u>ITCHES</u>	
Push Switch (NR Selector)	S 606,
Push Switch	S 608
(Power ON/OFF)	
Rotary Switch	
(AC Power Voltage Selector)	
Slide Switch	J 1, 2,
(Timer REC/PLAY)	
Push Switch	J 5, 6
(Mode Selector)	J 7
Key Board Switch	J 8
(Direction)	
Duble Key Board Switch	
(REC/F.F/REW)	

Q. No.	Part No.	Part Name & Description
506, 507	SSG13	Key Board Switch (Play/Pause/Stop)
	QSWY207	Duble Key Board Switch (Auto Rec Muto)
510, 511	SSG13	Key Board Switch (Counter Reset/Tape/Time)
	QSW1125	Key Board Switch with D523 (D.M.S 1)
	QSW1125	Key Board Switch with D524 (D.M.S 2)
	QSW1125	Key Board Switch with D525 (D.M.S 3)
	QSW1125	Key Board Switch with D526 (D.M.S 4)
	QSW1125	Key Board Switch with D527 (D.M.S 5)
	QSW1125	Key Board Switch with D528 (D.M.S 6)
	QSW1125	Key Board Switch with D529 (D.M.S 7)
	QSW1125	Key Board Switch with D530 (D.M.S 8)
	QSW1125	Key Board Switch with D531 (D.M.S 9)
	QSW1125	Key Board Switch with D532 (D.M.S 10)
	QSW1125	Key Board Switch with D533 (D.M.S 11)
	QSW1125	Key Board Switch with D534 (D.M.S 12)
	SSG13	Key Board Switch (Blank Skip)
	QSW1130	Tact Switch (Repeat)
	SSG13	Key Board Switch (D.M.S)
602, 603, 604, 605	QSB0296	Leaf Switch [Metal Tape/CrO ₂ Tape/ Half/FWD•REC Inhibit/ REV•REC Inhibit]
607	QSB0295	Leaf Switch (CAM B/CAM A)
	QSS4223	Slide Switch (FWD/REV Detector)
JACKS		
3, 4	QEJ5030C	Jack Board (LINE IN/OUT)
	QJA0453	Microphone Jack
	QJA0267	Headphones Jack
	QJS1955H	Remote Control Socket


TERMINATIONS




Part No.	Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.
ERD25TJ103 410, 411 ERD25FJ682 414, 415 ERD25FJ151 ERD25FJ562 ERD25FJ562 ERD25FJ562 ERD25FJ562 ERD25FJ471 439 ERD25FJ681 ERD25FJ471 ERD25FJ562 444, 445, 446, 447, ERD25TJ103 452, 453 ERD25FJ821 456, 457, 458, 459, ERD25FJ562 ERD25TJ223 ERD25FJ562 ERD25FJ103 ERD25TJ104 ERD25TJ181 a, Latin America, East and Africa ERG12ANJ271 European and a.] ERD25FJ182 ERD25FJ471 ERD25TJ684 ERD25TJ181 a, Latin America, East and Africa ERG1ANJ181 European and a.] ERD25FJ472 523 ERD25FJ103 ERD25TJ473 ERD25FJ103 ERD25TJ181 E RESISTORS QVNB3A00B223 QVNB3A00B103 QVBP1PUA54 QVAL5KUG15 QVNB3A00B222 QVBF1PUA14 QVNB3A00B222 QVNB3A00B474 306 QVNB3A00B103 QVNB3A00B223 EVNK4AA00B22 ACITORS ECEA50Z1 ECQM1H224JZ ECEA1ES4R7 ECDD1H820K ECEA50Z1 ECKD1H331KB ECEA0JS101 ECQM1H103JZ ECKD1H331KB ECFDD152KVY ECFDD122KVY ECEA1ES4R7 ECKD1H681KB ECEA50Z1 ECQM1H273JZ ECFDD472KVY ECEA50Z1 ECFDD223KXY ECEA1ES4R7 ECEA0JS470 ECKD1H223ZF ECDD1H221KD ECQP1682JZ ECFDD153KXY ECFDD822KVY ECEA1ES220 ECKD1H223ZF ECEA1CS331 ECKD1H223ZF ECEA1CS332 ECEA1CS222 ECEA1CS332 ECEA1CS330 [For all European and Australia.] ECEA1CS100 ECQM1H394JZ ECEA1ES4R7 ECEA1CS100 ECEA1CS221 ECEA1CS330 ECEA50Z1 ECQM1H104JZ ECQM1H474JZ ECEA1CS100 ECEA1ES4R7 ECEA50Z1 ECQM1H102JZ ECEA0JS101 ECEA1ES4R7 ECQP1333JZ ECFDD153KXY ECFDD822KVY ECEA1ES101 ECEA1CS101 ECEA1CS100 ECEA1CS222 ECQV1H104JZ ECQU2A103MF ECDD1H101KC ECDD1H330KC ECEA1HS010 ECEA1CS100 ECEA1HSR47 ECQM1H104JZ ECEA1ES4R7 ECFDD393KXD ECEA1CS100	C 61, 62 C 63, 64 C 65 C 66 C 67, 68 C 69, 70, 71, 72 C 73, 74, 75, 76 C 77, 78 C 79, 80 C 81, 82 C 83, 84 C 85, 86 C 87, 88 C 89, 90 C 91, 92 C 93, 94 C 95, 96 C 97, 98 C 99, 100 C 101 C 102, 103, 104 C 105 C 106 C 107, 108 C 109, 110 C 111, 112 C 113, 114 C 115, 116 C 117, 118 C 119, 120 C 125, 126, 127, 128 C 133, 134 C 137 C 138 C 139 C 301, 302 C 303 C 304 C 305 C 306, 307 C 308, 309 C 310, 311 C 312 C 314 C 315 C 316 C 317 C 318 C 319 C 320 C 324 C 325 C 326, 327 C 328 C 329 C 330 C 331 C 332 C 333 C 334 C 335 C 336 C 337 C 338 C 339 C 340 C 341 C 342 C 343 C 344 C 345 C 401 C 402 C 404 C 405 C 409 C 410 C 501, 502 C 505 C 506	ECQM1H333JZ ECQM1H224JZ ECQM1H222JZ ECEA1EN3R3 ECEA50ZR22 ECQM1H104JZ ECQM1H332JZ ECDD1H331K ECQM1H223JZ ECDD1H471K ECEA50MR68R ECEA1CS100 ECQM1H472JZ ECEA16Z10 ECQM1H333JZ ECEA50MR33R ECEA0JS470 ECQM1H391J ECQM1H223JZ ECEA1CS100 ECEA50Z1 ECEA1AS471 ECEA0JS331 ECEA1CS100 ECKD2H121KB ECKD1H561KB ECEA50ZR33 ECEA1CN100 ECQM1H273JZ ECFDD472KVY ECEA50Z1 ECFDD223KXY ECEA1ES4R7 ECEA0JS470 ECKD1H223ZF ECDD1H221KD ECQP1682JZ ECFDD153KXY ECFDD822KVY ECEA1ES220 ECKD1H223ZF ECEA1CS331 ECKD1H223ZF ECEA1CS332 ECEA1CS222 ECEA1CS332 ECEA1CS330 [For all European and Australia.] ECEA1CS100 ECQM1H394JZ ECEA1ES4R7 ECEA1CS100 ECEA1CS221 ECEA1CS330 ECEA50Z1 ECQM1H104JZ ECQM1H474JZ ECEA1CS100 ECEA1ES4R7 ECEA50Z1 ECQM1H102JZ ECEA0JS101 ECEA1ES4R7 ECQP1333JZ ECFDD153KXY ECFDD822KVY ECEA1ES101 ECEA1CS101 ECEA1CS100 ECEA1CS222 ECQV1H104JZ ECQU2A103MF ECDD1H101KC ECDD1H330KC ECEA1HS010 ECEA1CS100 ECEA1HSR47 ECQM1H104JZ ECEA1ES4R7 ECFDD393KXD ECEA1CS100	Z 3, 4 Z 5, 6 Z 301 Z 401, 402 Z 403 Z 404 Z 405 Z 406, 407 Z 408 Z 409 Z 410 Q 1, 2, 3 Q 4 Q 5, 6 Q 7, 8 Q 9, 10, 11, 12 Q 13, 14, 15, 16, 17, 18, 19, 20, 21, 22 Q 23, 24 Q 25, 26, 27, 28 Q 29, 30 Q 31, 32 Q 33, 34 Q 35, 36 Q 37, 38 Q 39, 40, 41, 42 Q 301, 302 Q 303 Q 304 Q 305 Q 306 Q 307 Q 308 Q 309 [D][B][A] 2SC3311 [For all European and Australia.] Q 310, 311, 312, 313 Q 314 Q 315 Q 316 Q 317 Q 318, 319, 320, 321, 322 Q 323 Q 324 Q 325, 326 Q 327 Q 328 Q 329, 330 Q 401, 402, 403, 404, 405, 406, 407, 408, 409, 410 Q 412, 413, 414, 415, 416, 417 Q 418 Q 419 Q 420 Q 421 Q 422 Q 423 Q 424 Q 425 Q 426 Q 427 Q 428, 429, 430, 431, 432, 433, 434, 435 Q 501 Q 502 Q 508, 509 Q 510 D 1 D 3, 4 D 5 D 6 D 301 D 302 D 303, 304, 305, 306, 307 D 308 D 309 D 310, 311, 312, 314, 315, 316, 317, 318, 319, 320, 321, 322, 323, 324, 325, 326, 327, 328, 329, 330	EXRP220K124 EXRP181K153 EXRP470K683 EXBEQ4272K EXBEQ4562K EXBEQ4102K EXBEQ4272K EXBEQ4563K EXBEQ4272K EXBEQ4472K EXFP4103ZW 2SD1011 2SB1036 2SD1450 2SK330GRY 2SD1450 2SC3311 2SD1011 2SC3311 2SA1115 2SK330GRY 2SJ105GR 2SD1450 2SA1115 2SC3311 2SD592 2SA719 2SA1115 UN4211TA 2SD1265OP 2SB941P 2SD1275 Q 309 [D][B][A] 2SC3311 [For all European and Australia.] Q 310, 311, 312, 313 Q 314 Q 315 Q 316 Q 317 Q 318, 319, 320, 321, 322 Q 323 Q 324 Q 325, 326 Q 327 Q 328 Q 329, 330 Q 401, 402, 403, 404, 405, 406, 407, 408, 409, 410 Q 412, 413, 414, 415, 416, 417 Q 418 Q 419 Q 420 Q 421 Q 422 Q 423 Q 424 Q 425 Q 426 Q 427 Q 428, 429, 430, 431, 432, 433, 434, 435 Q 501 Q 502 Q 508, 509 Q 510 MA1047 MA161 L0702DU MA161 MA1056 MA161 MA1062 MA161 MA161 MA1120 MA161 SLR34GC SLR34URC SLR34YC LN422YP SLR34GC SLR34URC SLR34GC 529, 530, 531, 532, 533, 534 refer to S512—S523 D 505, 506, 507 SSG13 QSWY207 S 509, 510, 511 SSG13 S 512 QSW1125 S 513 QSW1125 S 514 QSW1125 S 515 QSW1125 S 516 QSW1125 S 517 QSW1125 S 518 QSW1125 S 519 QSW1125 S 520 QSW1125 S 521 QSW1125 S 522 QSW1125 S 523 QSW1125 S 524 SSG13 S 525 QSW1130 S 526 SSG13 S 601, 602, 603, 604, 605 QSB0296 S 606, 607 QSB0295 S 608 QSS4223 J 1, 2, 3, 4 QEJ5030C QJA0453 QJA0267 QJS1955H J 5, 6 J 7 J 8	D 331, 332 D 333, 334 D 335 D 336, 337 D 338 D 339 D 340 D 401, 402, 403, 404, 405, 406, 407 D 409 D 410 D 411, 412, 413, 414, 415, 416, 417, 418, 419, 420, 421 MA161 D 501, 502, 503, 504, 505, 506, 507, 508, 509, 510, 511, 512, 513, 514, 515 MA161 D 516 D 517 D 518 D 519 D 520 D 521 D 522 D 523, 524, 525, 526, 527, 528, 529, 530, 531, 532, 533, 534 refer to S512—S523 D 505, 506, 507 SSG13 QSWY207 S 509, 510, 511 SSG13 S 512 QSW1125 S 513 QSW1125 S 514 QSW1125 S 515 QSW1125 S 516 QSW1125 S 517 QSW1125 S 518 QSW1125 S 519 QSW1125 S 520 QSW1125 S 521 QSW1125 S 522 QSW1125 S 523 QSW1125 S 524 SSG13 S 525 QSW1130 S 526 SSG13 S 601, 602, 603, 604, 605 QSB0296 S 606, 607 QSB0295 S 608 QSS4223 J 1, 2, 3, 4 QEJ5030C QJA0453 QJA0267 QJS1955H J 5, 6 J 7 J 8	D 622, 623, 624, 625, 626 QVDSL0050 (With ATS/Direction Circuit Board) INTEGRATED CIRCUITS IC 1 M5218L IC 2 M5220L IC 3, 4 NE654N IC 5, 6 NE652N IC 7 AN6258 IC 8 AN6291 IC 9, 10 AN6203 IC 11, 12 M5218L IC 301, 302 M5218L IC 401 MN1564RME IC 402 AN6271 IC 403 AN6270 IC 404, 405 DN6838 IC 501 AN6870N IC 502, 503 AN6280 F 601 QRUF10WH X 401 EF0A4R0M01A IC PROTECTOR CERAMIC RESONATOR		

Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description
MULTIPLEX FILTERS					
MPX 1, 2	QLM9Z10K	M.P.X Coil	S 505, 506, 507	SSG13	Key Board Switch (Play/Pause/Stop)
			S 508	QSWY207	Duble Key Board Switch (Auto Rec Muto)
			S 509, 510, 511	SSG13	Key Board Switch (Counter Reset/Tape/Time)
COILS					
L 1, 2	ELM7Q306A	Skewing Network	S 512	QSW1125	Key Board Switch with D523 (D.M.S 1)
L 3, 4	QLQX0343KWA	Bias Trap Coil	S 513	QSW1125	Key Board Switch with D524 (D.M.S 2)
L 5, 6	QLQX2722D	Peaking Coil	S 514	QSW1125	Key Board Switch with D525 (D.M.S 3)
L 7	QLQX1012DT	Choke Coil	S 515	QSW1125	Key Board Switch with D526 (D.M.S 4)
L 301, 302	QLB0198	Bias Oscillation Coil	S 516	QSW1125	Key Board Switch with D527 (D.M.S 5)
L 401	QLQX1012DT	Choke Coil	S 517	QSW1125	Key Board Switch with D528 (D.M.S 6)
L 601, 602, 603, 604	ELEH101KA	Choke Coil	S 518	QSW1125	Key Board Switch with D529 (D.M.S 7)
TRANSFORMER			S 519	QSW1125	Key Board Switch with D530 (D.M.S 8)
T 301	[D][B][A] QLPA76ELX	AC Power Transformer [For all European areas.]	S 520	QSW1125	Key Board Switch with D531 (D.M.S 9)
	[A][N] QLPA88ELX	AC Power Transformer [For Australia, Asia, Latin America, Middle East and Africa areas.]	S 521	QSW1125	Key Board Switch with D532 (D.M.S 10)
F 1 [N]	XBA2E03NS5	Fuse (300mA) [For Asia, Latin America, Middle East and Africa areas.]	S 522	QSW1125	Key Board Switch with D533 (D.M.S 11)
	[D][B][A] XBAQ100027	Fuse (T 1A) [For all European and Australia.]	S 523	QSW1125	Key Board Switch with D534 (D.M.S 12)
F 2	[D][B][A] XBAQ100027	Fuse (T 1A) [For all European and Australia.]	S 524	SSG13	Key Board Switch (Blank Skip)
S 1, 2, 3, 4	QSW2240	Push Switch (NR Selector)	S 525	QSW1130	Tact Switch (Repeat)
S 301	QSW1127	Push Switch (Power ON/OFF)	S 526	SSG13	Key Board Switch (D.M.S)
S 302	QSR1407	Rotary Switch (AC Power Voltage Selector)	S 601, 602, 603, 604, 605	QSB0296	Leaf Switch
S 401	QSS1306	Slide Switch (Timer REC/PLAY)	S 606, 607	QSB0295	Leaf Switch (CAM B/CAM A)
S 402	QSW2241	Push Switch (Mode Selector)	S 608	QSS4223	Slide Switch (FWD/REV Detector)
S 501	SSG13	Key Board Switch (Direction)	JACKS		
S 502, 503, 504	QSWY207	Duble Key Board Switch (REC/F.F./REW)	J 1, 2, 3, 4	QEJ5030C	Jack Board (LINE IN/OUT)
			J 5, 6	QJA0453	Microphone Jack
			J 7	QJA0267	Headphones Jack
			J 8	QJS1955H	Remote Control Socket

TERMINATIONS




CONNECTORS



DIAGRAM

For all European areas
except United Kingdom.
For United Kingdom.
For Asia, Latin America,
Middle East and Africa areas.
For Australia.



CIRCUIT BOARDS AND WIRING CONNECTION DIAGRAM

NOTES:

- D** For all European areas except United Kingdom.
- B** For United Kingdom.
- N** For Asia, Latin America, Middle East and Africa areas.
- A** For Australia.

I MAIN CIRCUIT BOARD

LUG TERMINAL
(to Mechanism Unit)

PHOTO
SENSOR

VII AC POWER TRANSFORMER CIRCUIT BOARD

LUG TERMINAL
(to Mechanism Unit)

FF/REW MOTOR

CAPSTAN MOTOR
**VI MECHANISM
CIRCUIT BOARD**

DRIVE MOTOR

S607: MODE
CHANGING SW

S606: FWD/REV
CHANGING SW

AC POW
TRANS

IV OPERATION SW CIRCUIT BO

V HEADPHONES JACK CIRCUIT BOARD

VII ATS/DIRECTION LED CIRCUIT BOARD

III FL METER CIRCUIT BOARD

XIII LED (D335) CIRCUIT BOARD

VI FWD/REV SELECT SW CIRCUIT BOARD

ERASE HEAD
(REVERSE)

ERASE HEAD
(FORWARD)

R/P HEAD
BOTTOM VIEW


ROTARY HEAD ASSY
(RECORD/PLAYBACK HEAD)

V SLIDE VOLUME CIRCUIT BOARD

CUIT BOARD



MECHANICAL PARTS LOCATION



NOTE:

- When changing mechanism parts, apply the specified grease to the area marked "xx" shown in the drawing "Mechanical Parts Location".
- (AK-152, AERO GREASE) The grease and/or oil shown in the parentheses function to prevent friction (lubrication).

SPECIFICATIONS


Pressure of pressure roller	400±50g
Takeup tension * Use cassette torque meter.....QZZSRKCT	50± 10g·cm (FWD & REV mode)
Wow and flutter; (JIS) * Use test tape QZZCWAT	Less than 0.1% (WRMS)

REPLACEMENT PARTS LIST

Ref. No.	Part No.	Part Name & Description
<u>MECHANICAL PARTS</u>		
M 1	QMA4620	Eject Angle
M 2	XTN2 + 8B	Tapping Screw $\oplus 2 \times 8$
M 3	QDB0347	Flywheel Belt
M 4	XTN3 + 8B	Tapping Screw $\oplus 3 \times 8$
M 5	XTN3 + 22B	Tapping Screw $\oplus 3 \times 22$
M 6	XSN26 + 10	Screw $\oplus 2.6 \times 10$
M 7	XTN3 + 6B	Tapping Screw $\oplus 3 \times 6$
M 8	QML4025	Change Lever

Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description
M 9	QXR0963	Change Rod Assembly	M 32	QTD1315	Cord Clamper	M 51-1	QBN1994	Click Spring
M 10	QDG1325	Sub Gear	M 34	QML4026	Obstruction Lever	M 51-2	QBP1993	Head Thrust Spring
			M 35	QMR2097	Eject Rod	M 51-3	XTN2 + 4B	Tapping Screw $\oplus 2 \times 4$
M 11	QDG1309	Main Gear	M 36	QBT1947	Eject Rod Spring	M 51-4	QBC1470	Head Spring
M 12	QBT2003	Eject Angle Spring	M 37	QXF0221	Flywheel (R) Assembly	M 51-5	QHQ1352	Screw
M 13	XTN2 + 14B	Tapping Screw $\oplus 2 \times 14$	M 39	QBW2116	Washer (2.4 ϕ)	M 52	QXK2855	Head Base Plate
M 14	QMA4628	Mechanism Angle-L	M 40	QXF0220	Flywheel (L) Assembly			Assembly
M 15	QMA4627	Mechanism Angle-R	M 42	QBW2117	Washer (2.7 ϕ)	M 53	QXL1654	Pinch Roller Arm (L)
M 16	XTN3 + 6B	Tapping Screw $\oplus 3 \times 6$	M 43	QXU0331	Capstan Motor Assembly			Assembly
M 17	QBW2046	Washer (3 ϕ)			(with Motor Governor	M 53-1	QBN1992	Pinch Roller Spring (L)
M 18	QDR1173	Reel Table			P.C.B.)	M 54	QBT1962	Obstruction Lever Spring
M 19	QBC1449	Reel Table Spring-L	M 44	QMA4619	Flywheel Holding Plate	M 55	QXL1655	Pinch Roller Arm (R)
M 20	QBC1450	Reel Table Spring-R						Assembly
			M 45	QMZ1315	Flywheel Thrust Retainer			
M 21	QBW2012	Washer (2.1 ϕ)	M 46	XSN26 + 3	Screw $\oplus 2.6 \times 3$	M 55-1	QBN1993	Pinch Roller Spring (R)
M 22	QBW2008	Washer (2 ϕ)	M 47	QXU0332	FF/REW Motor Assembly	M 56	QDB0253	Pulley Belt
M 23	XTN26 + 6B	Tapping Screw $\oplus 2.6 \times 6$	M 48	QXU0333	Drive Motor Assembly	M 57	QZE0063	End Sensor
M 24	QWY2148YC	Erase Head (FWD)	M 49	QXG1076	Center Gear Assembly	M 58	QXA1432	Magnet Pulley Angle
M 25	QWY2148W	Erase Head (REV)	M 49-1	QDG1307	Center Gear	M 59	QXP0632	Magnet Pulley Assembly
M 26	QBC1448	Erase Head Spring	M 49-2	QBW23007	Washer (2.5 ϕ)	M 60	QML4078	Switch Lever
M 27	XSN2 + 18	Screw $\oplus 2 \times 18$	M 49-3	QBH0151	Spacer	M 61	QBN2030	Switch Lever Spring
M 28	QHQ1364	Cup Screw	M 50	QBT1742	Head Base Plate Spring	M 62	QMH2107	Wire Clamper
M 30	QJT0015	Lug Terminal	M 51	QXV0195	Rotary Head Assembly	M 63	XTN26 + 8B	Tapping Screw $\oplus 2.6 \times 8$
M 31	QTW1342	Insulator Sheet			(Record/Playback Head)	M 64	QBW2059	Poly Washer $\phi 2.1$
						M 65	XTN26 + 4B	Tapping Screw $\oplus 2.6 \times 4$

CABINET PARTS LOCATION





REPLACEMENT PARTS LIST

Important safety notice
Components identified by Δ mark have special characteristics important for safety.

When replacing any of these components, use only manufacturer's specified parts.

Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.
CABINET PARTS							
G 1	[N] QYF0692	Cassette Lid [For Asia, Latin America, Middle East and Africa areas.]	G 7	QGL1190K	Meter Filter	G 27	refer to D622—626
	"Silver Type"		G 8	QGG0227	Slide Guide-A	G 28	QGC1247
	[N] QYF0692K	Cassette Lid [For Asia, Latin America, Middle East and Africa areas.]		QGG0229	Slide Guide-B	G 29	QKA1094
	"Black Type"			"Silver Type"		G 30	QMA4645
[D][B][A]	QYF0702	Cassette Lid [For all European and Australia.]		QGG0229K	Slide Guide-B	G 31	QKJ0609
	"Silver Type"		G 9	"Black Type"		G 32	QKJ0661
[D][B]	QYF0702K	Cassette Lid [For all European areas.]		QYT0657	Slide Knob-A Assembly (Output/Balance)	G 33	QMK2130
	"Black Type"		G 10	QYT0658	Slide Knob-B Assembly (Input)	G 34	QMR2059
	[D][B][A]	QYF0702	G 11	QMA4626	Holder Angle-L	G 35	QGO2142
	"Silver Type"		G 12	QGO2306	Eject Button	G 36	QGT1642
[D][B]	QYF0702K	Cassette Lid [For all European areas.]	G 13	QML4063	Eject Lever	G 37	QGO2310
	"Black Type"		G 14	QBP2007	Eject Lever Spring	G 38	QGO2311
G 2	QGC1245	Case Cover	G 15	QJC0064	Earth Plate	G 39	QGO2312
	"Silver Type"		G 16	QGO2309	Direction Button	G 40	QGO2313
	QGC1245K	Case Cover		"Silver Type"		G 41	QGO2314
	"Black Type"			QGO2309K	Direction Button	G 42	QGO2307R
G 3	QH1349	Ornament Screw		"Black Type"		G 43	QGO2307D
	"Silver Type"		G 17	QGO2315	Mode Select Button-A ()	G 44	QGO2307H
	QH1349K	Ornament Screw		"Silver Type"		G 45	QGO2346
	"Black Type"			QGO2315K	Mode Select Button-A ()	G 46	QTS1635
G 4	XTB3 + 8BFN	Tapping Screw $\Phi 3 \times 8$		"Black Type"		G 47	QMA4613
	"Silver Type"		G 18	QGO2316	Mode Select Button-B (for S301) ()	G 48	QKJ0608
	XTB3 + 8BFZ	Tapping Screw $\Phi 3 \times 8$		"Silver Type"		G 49	QKJ0725
	"Black Type"			QGO2316K	Mode Select Button-B (for S301) ()	G 50	QGK3355
G 5	QYP1212	Front Panel Assembly	G 19	QGO2317	Mode Select Button-C ()	G 51	QTH1184
	"Silver Type"			"Silver Type"		G 52	QTS1629
	QYP1212K	Front Panel Assembly		QGO2317K	Mode Select Button-C ()	G 53	QSiFM0008F
	"Black Type"			"Black Type"		G 54	QMK2100
G 5-1	QGK3467	Ornament Plate	G 20	QMB1429	Button Bushing	G 55	QMA4741
	"Silver Type"		G 21	QBC1473	Button Spring	G 56	QMA4740
	QGK3467K	Ornament Plate	G 22	QYF0697	Cassette Holder	G 57	QKJ0683
	"Black Type"			"Silver Type"		G 58	QMA4742
G 5-2	QMF2327	Button Retainer Plate		QYF0697K	Cassette Holder	G 59	QTS1625
G 5-3	QGO2344	D.M.S (I1)—(I2) Button	G 23	"Black Type"			
G 5-4	QGO2308	Function Button		QBP1925	Holder Spring	G 60	QMA4614
G 5-5	QGO2345	Counter Reset Button	G 24	QBN1961	Eject Spring	G 61	QMA4624
G 5-6	refer to D335	Mechanism Illuminate L.E.D	G 25			G 62	QMA4679
G 6	QGL1190	Meter Filter	[D][B][A]	QJT1079	Nylon Coupler		
	"Silver Type"		G 26	QYF0627	Dumper Gear Assembly		

CABINET PARTS LOCATION




REPLACEMENT PARTS LIST

Important safety notice

Components identified by Δ mark have special characteristics important for safety.

When replacing any of these components, use only manufacturer's specified parts.

Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description
CABINET PARTS											
G 1	[N] QYF0692	Cassette Lid	G 7	QGL1190K	Meter Filter	G 27	refer to	G 63	G 80	XTN3 + 6B	Tapping Screw @3×6
	[For Asia, Latin America, Middle East and Africa areas.]		G 8	QG0227	Slide Guide-A	G 28	D622—626	ATS/Direction L.E.D	G 81	XTN3 + 10B	Tapping Screw @3×10
	"Silver Type"			QG0229	Slide Guide-B	G 29	QKA1094	Bottom Cover	G 82	XTN3 + 12B	Tapping Screw @3×12
	[N] QYF0692K	Cassette Lid		"Silver Type"		G 30	QMA4645	Case Foot	G 83	XTN3 + 8B	Tapping Screw @3×8
	[For Asia, Latin America, Middle East and Africa areas.]			QG0229K	Slide Guide-B	G 31	QKJ0609	Remote Control Angle	G 84	QTS1636	Shield Plate-C
	"Black Type"		G 9	"Black Type"		G 32	QKJ0661	Nylon Rivet-A	G 85	QMA4789	Transformer Angle
	[D][B][A] QYF0702	Cassette Lid		QYT0657	Slide Knob-A Assembly (Output/Balance)	G 33	QMK2130	Nylon Rivet-B	G 86	QTD1315	Cord Clamper
	[For all European and Australia.]		G 10	QYT0658	Slide Knob-B Assembly (Input)	G 34	QMR2059	Back Chassis	G 87	[D][B][A] QTD1164	Cord Clamper-A [For all European and Australia.]
	"Silver Type"		G 11	QMA4626	Holder Angle-L	G 35	QGO2142	Power Switch Rod	G 88	[D][B][A] QTD1322	Cord Clamper-B [For all European and Australia.]
	[D][B] QYF0702K	Cassette Lid	G 12	QGO2306	Eject Button	G 36	QGT1642	Push Button (Power ON/OFF)	G 89	[D][B][A] QKJ0598	Switch Cover [For all European and Australia.]
[For all European areas.]		G 13	QML4063	Eject Lever	G 37	QGO2310	Timer Switch Knob	G90	[D][B][A] XTN3 + 24B	Tapping Screw @2.6×4 [For all European and Australia.]	
"Black Type"		G 14	QBP2007	Eject Lever Spring	G 38	QGO2311	NR Button-A ("C")				
G 2	QGC1245	Case Cover	G 15	QJC0064	Earth Plate	G 39	QGO2312	NR Button-B ("B")	G 65	QTWM0026	Switch Cover (for S302)
	"Silver Type"		G 16	QGO2309	Direction Button	G 40	QGO2313	NR Button-C ("OUT")	G 66	QTW1195	Spark Killer Cover
	QGC1245K	Case Cover		"Silver Type"		G 41	QGO2314	NR Button-D ("TAPE")	G 67	QMA4603	Switch Angle (for S302)
	"Black Type"			QGO2309K	Direction Button	G 42	QGO2307R	NR Button-E ("DISC")	G 68	[N] QMA3418	Fuse Angle [For Asia, Latin America, Middle East and Africa areas.]
G 3	QH01349	Ornament Screw		"Black Type"		G 43	QGO2307D	REC Button (Red)	G 69	[N] QTF1056	Fuse Holder [For Asia, Latin America, Middle East and Africa areas.]
	"Silver Type"		G 17	QGO2315	Mode Select Button-A ()	G 44	QGO2307H	Auto Rec Mute Button (Yellow)		[D][B][A] QTF1054	Fuse Holder [For all European and Australia.]
	QH01349K	Ornament Screw		"Silver Type"		G 45	QGO2346	Repeat Button (Gray)	G 70	XWA3B	Washer 3φ
G 4	XTB3 + 8BFN	Tapping Screw @3×8		QGO2315K	Mode Select Button-A ()	G 46	QTS1635	Shield Plate	G 71	XWG3	Washer 3φ
	"Silver Type"		G 18	QGO2316	Mode Select Button-B (for S301) ()	G 47	QMA4613	P.B Holding Angle-A	G 72	XS83 + 6FZS	Screw @3×6
	XTB3 + 8BFZ	Tapping Screw @3×8		"Silver Type"		G 48	QKJ0608	Tapping Support	G 73	XSN2 + 3	Screw @2×3
	"Black Type"			QGO2316K	Mode Select Button-B (for S301) ()	G 49	QKJ0725	Locking Support	G 74	XSN3 + 8S	Screw @3×8
G 5	QYP1212	Front Panel Assembly	G 19	QGO2317	Mode Select Button-C ()	G 50	QKG3355	Mic Cover	G 75	XTB3 + 8BFN	Tapping Screw @3×8
	"Silver Type"			"Silver Type"		G 51	QTH1184	Heat Sink	G 76	XTB3 + 10BFN	Tapping Screw @3×10
	QYP1212K	Front Panel Assembly		QGO2317K	Mode Select Button-C ()	G 52	QTS1629	Shield Plate-B (for Mechanism Control P.B)	G 77	XTB3 + 12BFN	Tapping Screw @3×12
G 5-1	QGK3467	Ornament Plate		"Black Type"		G 53	QSIFM008F	FL Meter	G 78	XTN26 + 5JFZ	Tapping Screw @2.6×5
	"Silver Type"		G 20	QMB1429	Mode Select Button-C ()	G 54	QMK2100	Operation Chassis	G 79	XTN26 + 6B	Tapping Screw @2.6×6
	QGK3467K	Ornament Plate		"Black Type"		G 55	QMA4741	P.B Holding Angle			
	"Black Type"		G 21	QBC1473	Button Bushing	G 56	QMA4740	Side Angle-R			
G 5-2	QMF2327	Button Retainer Plate	G 22	QYF0697	Button Spring	G 57	QKJ0683	LED Holder			
G 5-3	QGO2344	D.M.S ([1]—[12]) Button		"Silver Type"		G 58	QMA4742	Volume Angle			
G 5-4	QGO2308	Function Button		QYF0697K	Cassette Holder	G 59	QTS1625	Shield Plate-A (for Slid Volume)			
G 5-5	QGO2345	Counter Reset Button	G 23	"Black Type"							
			G 24	QBP1925	Holder Spring	G 60	QMA4614	Headphones Angle			
G 5-6	refer to D335	Mechanism Illuminate L.E.D		QBN1961	Eject Spring	G 61	QMA4624	Headphones Holding Plate			
G 6	QGL1190	Meter Filter	G 25			G 62	QMA4679	Side Angle-L			
	"Silver Type"		[D][B][A] QJT1079		Nylon Coupler						
			G 26	QYF0627	Dumper Gear Assembly						

Nr.: 318	Datum: 25. Februar 1985 WK/MM	4/85
THEMA	TEXT	
RS-B 58 R RS-B 78 R Statik-Geräusche Zu Nr. 2 pinch roller links QXL1809 pinch roller rechts QXL1808 Zu Nr. 3 QZZ0118	Symptom: Beanstandung von lauten Knackgeräuschen bei Wiedergabe im Abstand von 3 - 10 Minuten oder Knistergeräuschen. Grund: Während z.B. der Heizperiode oder geringer Luftfeuchtigkeit kann es vorkommen, daß laute Knackgeräusche bzw. ein Knistern hörbar wird bei der Wiedergabe. Statische Aufladung bzw. Entladung entstehen beim Bandtransport: a) A/W-Kopf b) an der Bandandruckrolle c) Vermittlungsrädchen Abhilfe: 1. Lt. Skizze eine Drahtverbindung herstellen. 2. Erneuerung der Bandandruckrolle durch die geänderte Version ET-Nr. pinch roller links QXL1809 pinch roller rechts QXL1808 3. Fetten der Vermittlungsrädchen ET-Nr. QZZ0118  (1) Add the Lead wire Panasonic Service Deutschland GmbH	